

FORM  
6Rev  
12/05

## State of Colorado

## Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80205 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Date Received:

Document Number:

400213265

## WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required.

Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 52530

Contact Name: Ryan Warner

Name of Operator: MAGPIE OPERATING, INC

Phone: (970) 669-6308

Address: 2707 SOUTH COUNTY RD 11

Fax: (970) 669-6396

City: LOVELAND State: CO Zip: 80537

Email: magpieoil@yahoo.com

For "Intent" 24 hour notice required,

Name: \_\_\_\_\_

Tel: \_\_\_\_\_

COGCC contact:

Email: \_\_\_\_\_

API Number 05-121-06122-00

Well Name: LITTLE BEAVER UNIT

Well Number: 64

Location: QtrQtr: SESE Section: 6 Township: 2S Range: 56W Meridian: 6

County: WASHINGTON

Federal, Indian or State Lease Number: \_\_\_\_\_

Field Name: LITTLE BEAVER

Field Number: 50200

☐ Notice of Intent to Abandon☒ Subsequent Report of Abandonment

## Only Complete the Following Background Information for Intent to Abandon

Latitude: 39.901815

Longitude: -103.690365

GPS Data:

Data of Measurement: 08/07/2009

PDOP Reading: 4.9

GPS Instrument Operator's Name: Ross M. Warner

Reason for Abandonment: ☐ Dry ☐ Production for Sub-economic ☐ Mechanical Problems☐ Other \_\_\_\_\_Casing to be pulled: ☐ Yes ☐ No Top of Casing Cement: \_\_\_\_\_Fish in Hole: ☐ Yes ☐ No If yes, explain details belowWellbore has Uncemented Casing leaks: ☐ Yes ☐ No If yes, explain details below

Details: \_\_\_\_\_

## Current and Previously Abandoned Zones

Formation	Code	Perf. Top	Perf. Bottom	Date	Method of Isolation	Plug Depth
D SAND	DSND	5193	5262	01/01/2002	B PLUG CEMENT TOP	1500

Total: 1 zone(s)

## Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/2	10+3/4	40.5	97	80	98	0	
1ST	9	5+1/2	15.5	5,321	200	5,321	4,445	

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 1500 with 2 sacks cmt on top. CIPB #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIPB #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 60 sks cmt from 1288 ft. to 1120 ft. Plug Type: OPEN HOLE Plug Tagged: ☒  
Set 50 sks cmt from 1120 ft. to 980 ft. Plug Type: OPEN HOLE Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 50 sacks half in. half out surface casing from 150 ft. to 45 ft. Plug Tagged: ☒

Set 25 sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: 10/08/2008

\*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_

Type of Cement and Additives Used: \_\_\_\_\_

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

see attached

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Ryan Warner

Title: VP Date: \_\_\_\_\_ Email: magpieoil@yahoo.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_

### CONDITIONS OF APPROVAL, IF ANY:

### Attachment Check List

Att Doc Num	Name
400213294	OTHER

Total Attach: 1 Files

**General Comments**

<b>User Group</b>	<b>Comment</b>	<b>Comment Date</b>

Total: 0 comment(s)