

Plugging Procedure: Equity-CALLUP #8 NSD

API # 05-103-07766

Surface Casing Set Depth: 32'

TD: 1704'

- 1) Run in hole with cable spool and confirm no bridges within 500' of surface
 - a. If bridges exist rig up cable tool rig to clean out.
- 2) Hand shovel shale cuttings on location from drilling process into hole from TD to 150' from surface.
- 3) Top off with Neet cement to surface, recording sacks used.
- 4) Cut off casing 6' below surface and weld plate with well identification.
- 5) Back fill location.
- 6) As built GPS previously recorded.