



DE ET OE ES

Document Number:  
400294612

Date Received:

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.  
 A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 66561 Contact Name: Rick Stevens  
 Name of Operator: OXY USA INC Phone: (970) 985-3003  
 Address: PO BOX 27757 Fax: (970) 263-3694  
 City: HOUSTON State: TX Zip: 77227 Email: rick\_stevens@oxy.com

**For "Intent" 24 hour notice required,** Name: LONGWORTH, MIKE Tel: (970) 812-7644  
**COGCC contact:** Email: mike.longworth@state.co.us

API Number 05-077-08444-00 Well Number: 26-32  
 Well Name: TEXACO-STARNER  
 Location: QtrQtr: SWNE Section: 26 Township: 9S Range: 94W Meridian: 6  
 County: MESA Federal, Indian or State Lease Number: \_\_\_\_\_  
 Field Name: BRUSH CREEK Field Number: 7562

Notice of Intent to Abandon  Subsequent Report of Abandonment

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 39.251110 Longitude: -107.845600  
 GPS Data:  
 Date of Measurement: 02/24/2011 PDOP Reading: 1.7 GPS Instrument Operator's Name: Dave Murrey  
 Reason for Abandonment:  Dry  Production for Sub-economic  Mechanical Problems  
 Other \_\_\_\_\_  
 Casing to be pulled:  Yes  No Top of Casing Cement: \_\_\_\_\_  
 Fish in Hole:  Yes  No If yes, explain details below  
 Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below  
 Details: \_\_\_\_\_

**Current and Previously Abandoned Zones**

Formation	Code	Perf. Top	Perf. Bottom	Date	Method of Isolation	Plug Depth
CORCORAN	CRCR N	7682	7709			

Total: 1 zone(s)

**Casing History**

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	369	175	369	0	VISU
1ST	7+7/8	4+1/2	11.6	7,814	785	7,814	5,275	CBL

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 470 with 39 sacks cmt on top. CIBP #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:

Perforate and squeeze at 4591 ft. with 25 sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
Perforate and squeeze at 4400 ft. with 30 sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
Perforate and squeeze at 1520 ft. with 30 sacks. Leave at least 100 ft. in casing 1470 CICR Depth  
(Cast Iron Cement Retainer Depth)

Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged:

Set \_\_\_\_\_ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: 06/02/2012

\*Wireline Contractor: Rocky Mountain Wireline Serv \*Cementing Contractor: Halliburton

Type of Cement and Additives Used: Plugcem (TM) System; fresh water

Flowline/Pipeline has been abandoned per Rule 1103  Yes  No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

Form 6 Intent to Abandon document #400288483 approved 5/25/2012.

An additional perf and squeeze was done at 710' with 252 sacks; CICR depth is 660'.

Fishing for 2 3/5" tubing was unsuccessful; top of fish is at 4,657'.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Joan Proulx

Title: Regulatory Analyst Date: \_\_\_\_\_ Email: joan\_proulx@oxy.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_

**CONDITIONS OF APPROVAL, IF ANY:**

### Attachment Check List

Att Doc Num	Name
400294614	WELLBORE DIAGRAM
400294615	CEMENT JOB SUMMARY
400294616	WIRELINE JOB SUMMARY

Total Attach: 3 Files

### General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>

Total: 0 comment(s)