

FORM  
6  
Rev  
02/11

State of Colorado **REVISED**  
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80205 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Date Received:  
2288617

Document Number:

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.  
A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 8005 Contact Name: Jim Whiting  
Name of Operator: Berry Energy Inc\*Walter Phone: (719) 688-0064  
Address: 1717 Washington Ave Fax: (303) 278-3461  
City: Golden State: CO Zip: 80401-19 Email: jimwhiting@gmail.com

For Intent 24 hour notice required, Name: \_\_\_\_\_ Tel: \_\_\_\_\_  
COGCC contact: Email: \_\_\_\_\_

API Number 05-099-06210---  
Well Name: Maddox Well Number: 7 #1  
Location: QtrQtr: N2SW Section: 23 Township: 22S Range: 45W Meridian: 6  
County: Prowers Federal, Indian or State Lease Number: \_\_\_\_\_  
Field Name: Clyde Field Number: 11435

Notice of Intent to Abandon  Subsequent Report of Abandonment

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 38.11953185 Longitude: -102.44443863  
GPS Data:  
Date of Measurement: 9/28/2010 PDOP Reading: 2.4 GPS Instrument Operator's Name: Matthew Cruson  
Reason for Abandonment:  Dry  Production for Sub-economic  Mechanical Problems  
 Other \_\_\_\_\_  
Casing to be pulled:  Yes  No Estimated Depth: \_\_\_\_\_  
Fish in Hole:  Yes  No If yes, explain details below  
Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below  
Details: \_\_\_\_\_

**Current and Previously Abandoned Zones**

Formation	Code	Perf. Top	Perf. Btm	Date	Method of Isolation	Plug Depth
Morrow		4622	4631			

Total: 0 zone(s)

**Casing History**

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
Surface	12 1/4"	8 5/8"	21 lbs	378'	375	378	0	
1st	7 7/8"	4 1/2"	10 1/2 lbs	4873'	200	4873	3940	Calc

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 4531' with 5 sacks cmt on top. CIPB #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIPB #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 20 sks cmt from 4631 ft. to 4531 ft. in Plug Type: Casing Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. in Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. in Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. in Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. in Plug Type: \_\_\_\_\_ Plug Tagged:

Perforate and squeeze at 1000 ft. with 40 sacks. Leave at least 100 ft. in casing 900' CICR Depth  
 Perforate and squeeze at 500 ft. with 175 sacks. Leave at least 100 ft. in casing 250' CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
(Cast Iron Cement Retainer Depth)

Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged:   
 Set 15 sacks at surface  
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No  
 Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_  
 \*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_

Type of Cement and Additives Used: \_\_\_\_\_

Flowline/Pipeline has been abandoned per Rule 1103  Yes  No \*ATTACH JOB SUMMARY

Provide Technical Detail:  
 \_\_\_\_\_

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: *Matthew Cruson* Print Name: Matthew Cruson  
 Title: \_\_\_\_\_ Date: 08/10/2012 Email: mac@berryenergyinc.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_

**CONDITIONS OF APPROVAL, IF ANY:**

--	--

### Attachment Check List

Att Doc Num	Name

Total Attach: \_\_\_\_\_

General Comments

User Group

Comment

Comment Date

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>

Total: