

*The Road to Excellence Starts with Safety*

|  |                                   |   |                        |
|--|-----------------------------------|---|------------------------|
| Sold To #: 304535                        | Ship To #: 2842033                | Quote #:                                  | Sales Order #: 8024669 |
| Customer: PDC ENERGY EBUS                |                                   | Customer Rep: Lefore, Tom                 |                        |
| Well Name: Skurich/SLW                   | Well #: 7D                        | API/UWI #: 05-123-20499                   |                        |
| Field: WATTENBERG                        | City (SAP): KERSEY                | County/Parish: Weld                       | State: Colorado        |
| Legal Description:                       |                                   |   |                        |
| Lat: N 0 deg. OR N 0 deg. 0 min. 0 secs. |                                   | Long: E 0 deg. OR E 0 deg. 0 min. 0 secs. |                        |
| Contractor:                              | Rig/Platform Name/Num:            |   |                        |
| Job Purpose: Plug to Abandon Service     |                                   | Ticket Amount:                            |                        |
| Well Type: Development Well              | Job Type: Plug to Abandon Service |   |                        |
| Sales Person: FLING, MATTHEW             | Svc Supervisor: KELEHER, JASON    | MBU ID Emp #: 437348                      |                        |

| Activity Description                             | Date/Time        | Cht # | Rate bbl/min | Volume bbl | Pressure psig | Comments |        |   |
|--|------------------|-------|--------------|------------|---------------|----------|--------|---|
|  |                  |       |              | Stage      | Total         | Tubing   | Casing |   |
| Arrive at Location from Other Job or Site        | 03/10/2011 07:00 |       |              |            |               |          |        |   |
| Pre-Rig Up Safety Meeting                        | 03/10/2011 07:10 |       |              |            |               |          |        |   |
| Rig-Up Equipment                                 | 03/10/2011 07:15 |       |              |            |               |          |        |   |
| Pre-Job Safety Meeting                           | 03/10/2011 08:00 |       |              |            |               |          |        |   |
| Test Lines                                       | 03/10/2011 08:24 | 2     | 2            |            |               |          |        | TEST LINES TO 3000 PSI                  |
| Pump Spacer                                      | 03/10/2011 08:30 | 3     | 5            |            |               |          |        | PUMP WATER SPACER                       |
| Pump Cement                                      | 03/10/2011 08:34 | 3     | 80           |            |               |          |        | PUMP 400 SKS OF PREMIUM G CMT @15.8 PPG |
| Shutdown   | 03/10/2011 09:00 | 0     | 0            |            |               |          | .0     | SHUT DOWN                               |
| Other  | 03/10/2011 09:05 |       |              |            |               |          |        | NO CMT RETURNS TO SURFACE               |
| Pre-Rig Down Safety Meeting                      | 03/10/2011 09:10 |       |              |            |               |          |        |   |
| Rig-Down Equipment                               | 03/10/2011 09:15 |       |              |            |               |          |        |   |
| Depart Location Safety Meeting                   | 03/10/2011 09:45 |       |              |            |               |          |        |   |
| Depart Location for Service Center or Other Site | 03/10/2011 09:50 |       |              |            |               |          |        |   |
| Arrive at Location from Other Job or Site        | 03/10/2011 13:30 |       |              |            |               |          |        |   |
| Assessment Of Location Safety Meeting            | 03/10/2011 13:45 |       |              |            |               |          |        |   |
| Test Lines                                       | 03/10/2011 14:30 |       |              |            |               |          |        | PRESSURE TEST TO 3000 PSI               |
| Pump Spacer 1                                    | 03/10/2011 14:34 | 2     | 2            |            |               |          | 56.0   | RIG WATER                               |

# **HALLIBURTON**

## *Cementing Job Log*

| Activity Description | Date/Time           | Cht # | Rate bbl/min | Volume bbl |       | Pressure psig |        | Comments  |
|----------------------|---------------------|-------|--------------|------------|-------|---------------|--------|---|
|                      |                     |       |              | Stage      | Total | Tubing        | Casing |   |
| Pump Cement          | 03/10/2011<br>14:45 |       | 3            | 92         |       |               | 660.0  | 450 SKS G NEAT MIXED AT 15.8 PPG WITH RIG WATER     |
| Shutdown             | 03/10/2011<br>15:13 |       |              |            |       |               |        | GOOD RETURNS THROUGHOUT JOB. CEMENT BACK TO SURFACE |
| End Job              | 03/10/2011<br>15:15 |       |              |            |       |               |        |   |