

Eichheim 18-9-66 1H (05-123-34080) Plugging

- 12/11/2012** MIRU WL, RIH/ SET CIBP, SPOT CEMENT ON PLUG, RDMO
NOTIFY JIM PRECUP W/ COGCC AT START OF DAY P/A WORKMIRU
WL, ND NIGHT CAP(0 PSI) FILL CASING,RIH W/ CIBP SET AT 6790
WL DEPTH, POHRIH W/ CEMENT DUMP BAILER SPOT CEMENT ON
CIBP, POHPOH, NU NIGHTCAP, RDMO WL, SDFN
- 12/14/2012** RU WOR, RU WL, RIH W/ SPLITSHOT CUT CASING
NOTIFY JIM PRECUP W/ COGCC OF CONTINUED OPERATIONMIRU
WOR, STBY FOR WL, MIRU WLRIH W/ SPLITSHOT AND CUT CASING
AT 1234' WL DEPTH. RDMO WLSDFN
- 12/15/2012** POOH W/ 5.5" CSG. PLACE STUB/SHOE PLUG.
NOTIFY JIM PRECUP W/ COGCC OF CONTINUED OPERATIONND B-
SECTION. BACK OFF HANGER PINS AND POOH W/ 5.5" CASING.LAY
DOWN 26 JTS (1214').PU AND RIH W/ 2 3/8" TBG TO 1284'.PUMP 90
SXS OF 15.8#, CLASS G CEMENT PLACING FROM 1027'-1284'.POOH
W/ TBG.SECURE WELL.SDFN.
- 12/16/2012** RIH W/ TBG AND TAG STUB/SHOE PLUG. POOH TO SURFAC
NOTIFY JIM PRECUP W/ COGCC OF CONTINUED OPERATION.RIH
W/ TBG AND TAG STUB/SHOE PLUG TOP @ 1027'.POOH W/ TBG
AND SPOT 40 SXS (100') OF 15.8#, CLASS G CEMENT @
SURFACE.RDMO WO RIG.CUT CASING 4' BELOW SURFACE, WELD
ON INFO PLATE, REMOVE CELLAR RING, AND BURY.CLEAN AND
DRESS PAD.