

Sauley #3

3-17-08

Rigged up and POOH w/rods. Laid down 204 - $\frac{3}{4}$ " rods. SDFN.

3-18-08

Tubing stuck. Worked tubing for several hours, but cannot get free. Loaded tubing and pressured to 1100#. Would not take any fluid. RIH w/sinker bar. Depthometer indicated stack out at 4314'. SDFN.

3-20-08

J/W Wireline ran free point test. Tubing free at approx 3600'. Shot tubing off at 3517' and POOH. SDFN.

3-21-08

RIH w/tubing to 1500' & circulated hole clean. RIH to 2500' & circulated hole clean. RIH to 3500' & circulated hole clean. POOH w/tubing. J/W Wireline shot squeeze holes at 3300' and set a cement retainer at 3200'. RIH w/tubing and stung into retainer. SDFN.

3-26-08

Western Wellsite Service pumped a 60 sack cement plug thru the retainer and a five sack plug on top of retainer. Worked casing for several hours. J/W Wireline

Saulcy #3

3-26-08
(Cont.)

shot casing off at 2635'. SDFN.

3-27-08

POOH w/ 4 1/2" casing and laid it down. Approx 2600'. RIH w/ 8jts 2 3/8" tubing. Western Wellsite Service pumped a 180 sack plug from 275' to surface. Well Plugged.