

Taiga Fed 12-25

9 5/8" 36# 310' TOC @ Surface

5 1/2" 15.5# 7069' TOC @ 3290'

CIBP @ 6840'

PBTD @ 6840

1. MIRU
2. RIH w/ CIBP, Set @ 6650
3. Dump bail 2 sk cmt on top of the CIBP
4. RIH w/ 2 3/8" tbg, Set 100' plug @ 3240'-3340'
5. RIH w/ 2 3/8" tbg, Set 100' plug @ 360'-260'
6. RD BOP
7. Set cement plug @ surface
8. Cut well head
9. Weld on well info