

US ROCKIES REGION

Anadarko Daily Summary Report

Well: SCHLAGEL 14-4

Project:COLORADO-WELD-NAD83-UTM13

Site:SCHLAGEL 14-4

Rig Name No:BASIC 1549/1549

Event: ABANDONMENT

Start Date: 11/13/2013

End Date: 12/17/2013

Spud Date: 1/15/1994

Active Datum: RKB @4,856.99usft (above Mean Sea Level)

UWI: 0/3/N/67/W/4/0/SWSW/6/0/0/0/0/0/0

Report No	Report Date	MD (usft)	24 Hr Summary
1	11/13/2013		MIRU Basic 1549. Kill well. ND well head. NU BOP. SI. SDFN.
2	11/14/2013		TOOH w/1 1/4" tbg. RU Canary & VES & run gyro. RU Warrior & run 2.125" gauge ring. Set 2 7/8" CIBP @ 6850'. TIH w/ 1 1/4" tbg to 6840'. SI. SDFN.
3	11/15/2013		RU Sanjel. Spot 10 sks G cmt on top of CIBP @ 6850'. Plug from 6840' to 6370'. LD 1 1/4" tbg. RU Warrior. Cut off 2 7/8" csg @ 4824'. TOOH. PU 3 jts 1 1/4" tbg & TIH w/2 7/8" tbg. Set tbg w/ btm @ 4890'. SI. SDFN.
4	11/16/2013		RU Sandjel to set plug across Sussex from 4890' to 2950' w/575 sx G cmt. TOOH. Wait 4 hrs. Tag cmt @ 2950'. LD tbg to set @ 825'. SI. SDFN.
5	11/17/2013		RU Sanjel & spot cmt plug from 825' to 532' w/175 sx Type III cmt w/2% Cacl2, & 1/4 #/sk Polyflake. LD tbg. ND BOP. WOC. RU Warrior & tag cmt @ 532'. PU tbg. Wait on Sanjel. RU Sanjel & spot plug from 532' to 330' w/50 sks Type III cmt. LD tbg. SI. SDFN.
6	11/19/2013		NDBOP. RU Warrior. Tag cement at 295. Set 8 5/8 CIBP at 100. NUBOP. Test CIBP to 1000. NDBOP. RDMO.
7	12/17/2013		Crew travel, safety. Dug up surface casing. Cut casing 6' below GL. Tagged @ 115'. Filled casing stub w 52 bags 5000# cement. Capped casing w metal plate containing well info. Backfilled.
8	12/17/2013		TIME : 13:00, ROUTE : N22, WINS: 75712, PROJECT TYPE: P&A, PROD: NB/CD, BATT#: 34003352, GATHERER: DCP, STATION: 232773, LINE : UNKNOWN, COMMENTS: P&A'd OFFLINE.