

FORM

6

Rev  
12/05

## State of Colorado

## Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

400554563

Date Received:

## WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 100322

Contact Name: Erich Zwaagstra

Name of Operator: NOBLE ENERGY INC

Phone: (970) 371-7884

Address: 1625 BROADWAY STE 2200

Fax: (970) 304-5099

City: DENVER State: CO Zip: 80202

Email: Ezwaagstra@nobleenergyinc.com

For "Intent" 24 hour notice required,

Name: \_\_\_\_\_

Tel: \_\_\_\_\_

COGCC contact:

Email: \_\_\_\_\_

API Number 05-123-11361-00

Well Name: TODD

Well Number: 9-1

Location: QtrQtr: NENE Section: 9 Township: 4N Range: 65W Meridian: 6

County: WELD

Federal, Indian or State Lease Number: 62454

Field Name: WATTENBERG

Field Number: 90750

☐ Notice of Intent to Abandon☒ Subsequent Report of Abandonment

## Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.332457

Longitude: -104.661003

GPS Data:

Date of Measurement: 06/08/2006

PDOP Reading: 3.8

GPS Instrument Operator's Name: David Gipson

Reason for Abandonment: ☐ Dry ☐ Production for Sub-economic ☐ Mechanical Problems☐ Other \_\_\_\_\_Casing to be pulled: ☐ Yes ☐ No

Estimated Depth: \_\_\_\_\_

Fish in Hole: ☐ Yes ☐ No

If yes, explain details below

Wellbore has Uncemented Casing leaks: ☐ Yes ☐ No

If yes, explain details below

Details: \_\_\_\_\_

## Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	7073	7086	01/08/2014	B PLUG CEMENT TOP	7013

Total: 1 zone(s)

## Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	213	230	213	0	VISU
1ST	7+7/8	4+1/2	11.6	7,203	160	7,203	6,728	CBL

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7013 with 2 sacks cmt on top. CIPB #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIPB #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 100 sks cmt from 4818 ft. to 5018 ft. Plug Type: STUB PLUG Plug Tagged: ☐  
Set 50 sks cmt from 2312 ft. to 2512 ft. Plug Type: CASING Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 362 sacks half in. half out surface casing from 385 ft. to 0 ft. Plug Tagged: ☒

Set \_\_\_\_\_ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing

Plugging Date: 01/10/2014

\*Wireline Contractor: Nabors Completion & Production

\*Cementing Contractor: Bison Oil Well Cementing

Type of Cement and Additives Used: G Neat 15.8 PPG

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No

\*ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_

Print Name: Mariln Tucker

Title: Engineering Tech

Date: \_\_\_\_\_

Email: Mtucker@nobleenergyinc.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_

Date: \_\_\_\_\_

### CONDITIONS OF APPROVAL, IF ANY:

#### COA Type

#### Description

--	--

### Attachment Check List

#### Att Doc Num

#### Name

400554573	WIRELINE JOB SUMMARY
400554576	WELLBORE DIAGRAM

Total Attach: 2 Files

## General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>

Total: 0 comment(s)