

FORM  
6

Rev  
12/05

State of Colorado  
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
----	----	----	----

Replug By Other Operator

Document Number:

400584381

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 47120 Contact Name: CHERYL LIGHT  
 Name of Operator: KERR-MCGEE OIL & GAS ONSHORE LP Phone: (720) 929-6461  
 Address: P O BOX 173779 Fax: (720) 929-7461  
 City: DENVER State: CO Zip: 80217- Email: CHERYL.LIGHT@ANADARKO.COM

**For "Intent" 24 hour notice required,** Name: MONTOYA, JOHN Tel: (970) 3974124  
**COGCC contact:** Email: john.montoya@state.co.us

API Number 05-123-08243-00  
 Well Name: APOLLO Well Number: 1  
 Location: QtrQtr: NENE Section: 19 Township: 1N Range: 65W Meridian: 6  
 County: WELD Federal, Indian or State Lease Number: \_\_\_\_\_  
 Field Name: WATTENBERG Field Number: 90750

Notice of Intent to Abandon  Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.041259 Longitude: -104.700846  
 GPS Data:  
 Date of Measurement: \_\_\_\_\_ PDOP Reading: \_\_\_\_\_ GPS Instrument Operator's Name: \_\_\_\_\_  
 Reason for Abandonment:  Dry  Production for Sub-economic  Mechanical Problems  
 Other RE-PLUG  
 Casing to be pulled:  Yes  No Estimated Depth: \_\_\_\_\_  
 Fish in Hole:  Yes  No If yes, explain details below  
 Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below

Details: This well was originally abandoned in 1978. Production casing could not be pulled due to cemented DV tool at 1112'. Well is to be re-entered to add cement coverage above the Niobrara, across the Sussex, and the Fox Hills into the surface casing. The CIBP @7000' will be drilled out and replaced with a CIBP w/cmt cap at 7800'.

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
J SAND	7861	7876	02/03/1978	B PLUG CEMENT TOP	7000

Total: 1 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	260	225	260	0	VISU
1ST	7+7/8	4+1/2	11.6	7,960	300	7,960	6,970	CALC
S.C. 1.1				1,112	250	1,112	724	CALC

### Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7800 with 2 sacks cmt on top. CIBP #2: Depth 100 with 8 sacks cmt on top.  
 CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:

Perforate and squeeze at 6550 ft. with 190 sacks. Leave at least 100 ft. in casing 6580 CICR Depth  
 Perforate and squeeze at 4310 ft. with 630 sacks. Leave at least 100 ft. in casing 4340 CICR Depth  
 Perforate and squeeze at 120 ft. with 320 sacks. Leave at least 100 ft. in casing 150 CICR Depth  
 (Cast Iron Cement Retainer Depth)

Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged:   
 Set 8 sacks at surface  
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No  
 Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_  
 \*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_  
 Type of Cement and Additives Used: \_\_\_\_\_  
 Flowline/Pipeline has been abandoned per Rule 1103  Yes  No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

As-built well location GPS data will be submitted on the Form 6 Subsequent Report of Abandonment.  
 Perforate and squeeze at 6950'/6550' ft. with 190 sacks Leave at least 100 ft. in casing 6580' CICR Depth  
 Perforate and squeeze at 4920'/4310' ft. with 630 sacks Leave at least 100 ft. in casing 4340' CICR Depth  
 Perforate and squeeze at 710'/120' ft. with 320 sacks Leave at least 100 ft. in casing 150' CICR Depth

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: CHERYL LIGHT  
 Title: SR. REGULATORY ANALYST Date: \_\_\_\_\_ Email: DJREGULATORY@ANADARKO.COM

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: \_\_\_\_\_ Expiration Date: \_\_\_\_\_

<u>COA Type</u>	<u>Description</u>

**Attachment Check List**

<u>Att Doc Num</u>	<u>Name</u>
400587073	OTHER
400587075	OTHER
400587076	WELLBORE DIAGRAM
400587077	PROPOSED PLUGGING PROCEDURE

Total Attach: 4 Files

**General Comments**

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>

Total: 0 comment(s)