

## US ROCKIES REGION

## Anadarko Daily Summary Report

Well: VANTAGE ACRES #1(24-17)

Project: COLORADO-WELD-NAD83-UTM13

Site: VANTAGE ACRES #1(24-17)

Rig Name No: ECWS 19/19

Event: RE ENTER

Start Date: 4/30/2014

End Date:

Spud Date: 8/12/1972

Active Datum: RKB @4,978.00usft (above Mean Sea Level)

UWI: VANTAGE ACRES #1(24-17)

Report No	Report Date	MD (usft)	24 Hr Summary
1	04/30/2014		Move in and rig out all lines & equipment. Could not rig up due to high winds. SDFN.
2	05/01/2014		RU rig. NUBOP. PU 7 7/8 rock bit, 4.75 DC. Strip into hole. Wait on electrician to fix gen. Tag cement at 5'. Drilled to 60'. SDFN.
3	05/02/2014		Drilled out cement from 55' to 215'. SDFN.
4	05/05/2014		Drilled out of cement at 220. Started circ 9.2# mud. Circ down to 630. Drilled out cement to 663. Last 3 hr made 15'. TOO H to check bit. Bit is OK. SDFN.
5	05/06/2014		TIH. Drilled cement to 854'. Circ. TOO H into surface csg. SDFN.
6	05/07/2014		TIH. Tag at 630. Drilled & circ to 760' Getting lots of shale in returns. PU into surface csg. SDFN.
7	05/08/2014		Change out bit. TIH. Tag at 600'. RU power swivel. Drill/clean out to 760'. Getting shale in returns. Circ. Pull up into surface csg. SDFN.
8	05/09/2014		TIH. Tag at 663'. PU power swivel. Drill/ clean out to 822' Circ. LD power swivel. PU into surface csg. SDFN.
9	05/12/2014		TIH. Tag at 344'. PU power swivel. Circ / drill out shale. Drilled to 837. Getting shale & old mud in returns.
10	05/13/2014		Drill / clean out to 970. TOO H. Check bit. TIH. Hit tight spot at 690. PU power swivel. Drilled thru tight spot. got back to 960.
11	05/14/2014		Drill / clean out to 1044. Getting fine shale & mud back in returns. Power swivel started leaked. Switch out power swivel. Drill to 1055.
12	05/15/2014		Started drilling at 1055'. Drilled to 1123' at midnite. Still getting some old mud & shale in returns.
13	05/16/2014		Drill out to 1128 (5' gain) in 6 hr. TOO H. Change out bit. TIH. Hit tight spot at 690. Lost circ. Had a plugged line. TOO H. Change bit to 6 1/8". TIH. tag at 1128. Started drilling again. Drilled to 1165 at midnite.
14	05/17/2014		Drill from 1165' to 1234' at midnite. Still getting mud & shale in returns.
15	05/18/2014		Circ. TOO H. LD DC & bit. TIH w/ muleshoe & tbg to 1234. Circ. RU Sanjel. Pumped 450 sx Type 3 cement. Got cement back in returns. TOO H & LD tbg. Circ at 90'. SDFN.
16	05/19/2014		ND bird bath. RU Pioneer. Tag cement at 95. Set 8 5/8 CIBP at 85'. Test CIBP to 1000# for 15 min. Held good. NDBOP. RDMO.
17	06/06/2014		Crew travel, safety. Dug up surface casing. Cut casing 6' below GL. Tagged @ 74'. Filled casing stub with 45 bags 5000# cement. Capped casing with metal plate containing well info. Backfilled.