

FORM

6

Rev
12/05

State of Colorado

Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



| | | | |
|----|----|----|----|
| DE | ET | OE | ES |
|----|----|----|----|

Replug By Other Operator

Document Number:

400637189

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required.

Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 10439

Contact Name: Cynthia Pinel

Name of Operator: CARRIZO NIOBRARA LLC

Phone: (713) 358-6210

Address: 500 DALLAS STREET #2300

Fax:

City: HOUSTON

State: TX

Zip: 77002

Email: cynthia.pinel@crzo.net

For "Intent" 24 hour notice required,

Name: Rains, Bill

Tel: (970) 590-6480

COGCC contact:

Email: bill.rains@state.co.us

API Number 05-123-14187-00

Well Name: DENNIS

Well Number: F

Location: QtrQtr: SENW

Section: 33

Township: 9N

Range: 58W

Meridian: 6

County: WELD

Federal, Indian or State Lease Number:

Field Name: WILDCAT

Field Number: 99999

☒ Notice of Intent to Abandon☐ Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.709335

Longitude: -103.871156

GPS Data:

Date of Measurement:

PDOP Reading:

GPS Instrument Operator's Name:

Reason for Abandonment: ☐ Dry☐ Production for Sub-economic☐ Mechanical Problems☒ Other Re-enter & PlugCasing to be pulled: ☐ Yes☐ No

Estimated Depth:

Fish in Hole: ☐ Yes☐ No

If yes, explain details below

Wellbore has Uncemented Casing leaks: ☐ Yes☐ No

If yes, explain details below

Details:

The scope of this work is to re-enter the old wellbore that had previously been plugged and abandoned. The well will be properly plugged and abandoned by setting cement plugs to isolate the formation, freshwater zone, and setting a cement cap near the surface. Then the surface casing will have a plate welded as final seal 5' below the surface. The old wellbore will then be buried and the surface location will be remediated.

Current and Previously Abandoned Zones

| Formation | Perf. Top | Perf. Btm | Abandoned Date | Method of Isolation | Plug Depth |
|-----------|-----------|-----------|----------------|---------------------|------------|
| D SAND | 6358 | | | | |
| J SAND | 6446 | | | | |
| NIOBRARA | 5590 | | | CEMENT | |

Total: 3 zone(s)

Casing History

| Casing Type | Size of Hole | Size of Casing | Weight Per Foot | Setting Depth | Sacks Cement | Cement Bot | Cement Top | Status |
|-------------|--------------|----------------|-----------------|---------------|--------------|------------|------------|--------|
| SURF | 12+1/4 | 9+5/8 | 24 | 182 | 35 | 182 | 0 | CALC |

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth _____ with _____ sacks cmt on top. CIPB #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIPB #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 86 sks cmt from 5590 ft. to 5290 ft. Plug Type: OPEN HOLE Plug Tagged: ☐
Set 173 sks cmt from 600 ft. to 0 ft. Plug Type: CASING Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged: ☐

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No *ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Cynthia Pinel

Title: Regulatory Comp. Analyst Date: _____ Email: cynthia.pinel@crzo.net

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY: _____

Expiration Date: _____

Attachment Check List

Att Doc Num

Name

| | |
|-----------|-----------------------------|
| 400637199 | WELLBORE DIAGRAM |
| 400637200 | PROPOSED PLUGGING PROCEDURE |
| 400637201 | WELLBORE DIAGRAM |
| 400637202 | SURFACE OWNER CONSENT |
| 400637203 | LOCATION PHOTO |

Total Attach: 5 Files

General Comments

User Group

Comment

Comment Date

| | | |
|--|--|--|
| | | |
|--|--|--|

Total: 0 comment(s)