

Stegas 23-15 1

Township 11 South, Range 53 West of the 6th P.M.

Section 15: NESW (1980' FSL, 1993' FWL)

Lincoln County, CO

Re-Entry Procedure

1. Excavate existing 8-5/8" casing stub, weld on extension
2. Excavate drilling rig location, dig drilling pit & freshwater pit
3. MIRU drilling rig, MU 7-7/8" mill tooth bit, drill collars
4. Drill out existing cement plugs to original TD
5. Run and 5.5" 15.5# casing to original TD, cement in place with 200sx cement
6. Cement port collars to cover Cheyenne & Dakota per APD
7. Perforate & test multiple objectives
8. Complete as a producer if tests are commercial, PA if not commercial