



**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 61250 Contact Name: MARK SHREVE  
 Name of Operator: MULL DRILLING COMPANY INC Phone: (316) 264-6366  
 Address: 1700 N WATERFRONT PKWY B#1200 Fax: (316) 264-6440  
 City: WICHITA State: KS Zip: 67206- Email: MSHREVE@MULLDRILLING.COM

**For "Intent" 24 hour notice required,** Name: \_\_\_\_\_ Tel: \_\_\_\_\_  
 COGCC contact: Email: \_\_\_\_\_

API Number 05-061-06893-00  
 Well Name: SCHERLER Well Number: 1-10  
 Location: QtrQtr: NENE Section: 10 Township: 17S Range: 45W Meridian: 6  
 County: KIOWA Federal, Indian or State Lease Number: \_\_\_\_\_  
 Field Name: WILDCAT Field Number: 99999

Notice of Intent to Abandon  Subsequent Report of Abandonment

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 38.596830 Longitude: -102.438610  
 GPS Data:  
 Date of Measurement: 09/30/2014 PDOP Reading: 2.7 GPS Instrument Operator's Name: ELIJAH FRANE  
 Reason for Abandonment:  Dry  Production for Sub-economic  Mechanical Problems  
 Other \_\_\_\_\_  
 Casing to be pulled:  Yes  No Estimated Depth: \_\_\_\_\_  
 Fish in Hole:  Yes  No If yes, explain details below  
 Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below  
 Details: \_\_\_\_\_

**Current and Previously Abandoned Zones**

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth

Total: 0 zone(s)

**Casing History**

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	341	265	341	0	CALC

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIPB #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIPB #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 40 sks cmt from 4890 ft. to 4790 ft. Plug Type: OPEN HOLE Plug Tagged:   
 Set 40 sks cmt from 3152 ft. to 3052 ft. Plug Type: OPEN HOLE Plug Tagged:   
 Set 40 sks cmt from 1850 ft. to 1750 ft. Plug Type: OPEN HOLE Plug Tagged:   
 Set 40 sks cmt from 1250 ft. to 1150 ft. Plug Type: OPEN HOLE Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
(Cast Iron Cement Retainer Depth)

Set 50 sacks half in. half out surface casing from 390 ft. to 290 ft. Plug Tagged:   
 Set 15 sacks at surface  
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No  
 Set 5 sacks in rat hole Set 5 sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: 08/31/2014  
 \*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: BASIC ENERGY SERVICES  
 Type of Cement and Additives Used: COMMON, NO ADDITIVES  
 Flowline/Pipeline has been abandoned per Rule 1103  Yes  No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

LEFT 1575' OF DRILLPIPE IN HOLE FROM 3152' TO 4727'.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: TANNIS TRITT  
 Title: EXECUTIVE ASSISTANT Date: \_\_\_\_\_ Email: TTRITT@MULLDRILLING.COM

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_

**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_

### Attachment Check List

Att Doc Num	Name
400700839	CEMENT JOB SUMMARY
400700840	WELLBORE DIAGRAM

Total Attach: 2 Files

## General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>

Total: 0 comment(s)