



DE	ET	OE	ES
Document Number: <div>400716333</div>			
Date Received:			

SUNDRY NOTICE

Submit a signed original. This form is to be used for general, technical and environmental sundry information. For proposed or completed operations, describe in full in Comments or provide as an attachment. Identify Well by API Number; identify Oil and Gas Location by Location ID Number; identify other Facility by Facility ID Number.

OGCC Operator Number: 100322	Contact Name KATHLEEN MILLS	<div>Complete the Attachment Checklist</div> <div>OP OGCC</div>
Name of Operator: NOBLE ENERGY INC	Phone: (720) 587-2226	
Address: 1625 BROADWAY STE 2200	Fax: (303) 228-4286	
City: DENVER State: CO Zip: 80202	Email: kmills@nobleenergyinc.com	
API Number : 05- 123 20598 00	OGCC Facility ID Number: 261445	Survey Plat
Well/Facility Name: HSR-FRICO	Well/Facility Number: 13-15	Directional Survey
Location QtrQtr: SWSW Section: 15 Township: 3N Range: 65W Meridian: 6		Srfc Eqpmt Diagram
County: WELD Field Name: WATTENBERG		Technical Info Page
Federal, Indian or State Lease Number:		Other

CHANGE OF LOCATION OR AS BUILT GPS REPORT

☐ Change of Location \*
☐ As-Built GPS Location Report
☐ As-Built GPS Location Report with Survey

\* Well location change requires new plat. A substantive surface location change may require new Form 2A.

SURFACE LOCATION GPS DATA

Data must be provided for Change of Surface Location and As Built Reports.

Latitude

PDOP Reading

Date of Measurement

Longitude

GPS Instrument Operator's Name

LOCATION CHANGE (all measurements in Feet)

Well will be:

(Vertical, Directional, Horizontal)

Change of Surface Footage From Exterior Section Lines:

Change of Surface Footage To Exterior Section Lines:

Current Surface Location From

QtrQtr SWSW

Sec 15

Twp 3N

Range 65W

Meridian 6

New Surface Location To

QtrQtr

Sec

Twp

Range

Meridian

Change of Top of Productive Zone Footage From Exterior Section Lines:

Change of Top of Productive Zone Footage To Exterior Section Lines:

Current Top of Productive Zone Location From

Sec

Twp

Range

New Top of Productive Zone Location To

Sec

Twp

Range

Change of Bottomhole Footage From Exterior Section Lines:

Change of Bottomhole Footage To Exterior Section Lines:

Current Bottomhole Location

Sec

Twp

Range

New Bottomhole Location

Sec

Twp

Range

Is location in High Density Area?

Distance, in feet, to nearest building

, public road:

, above ground utility:

, railroad:

property line:

, lease line:

, well in same formation:

Ground Elevation

feet

Surface owner consultation date

**CHANGE OR ADD OBJECTIVE FORMATION AND/OR SPACING UNIT**

<u>Objective Formation</u>	<u>Formation Code</u>	<u>Spacing Order Number</u>	<u>Unit Acreage</u>	<u>Unit Configuration</u>

**OTHER CHANGES**

☐ **REMOVE FROM SURFACE BOND** Signed surface use agreement is a required attachment

☐ **CHANGE OF WELL, FACILITY OR OIL & GAS LOCATION NAME OR NUMBER**

From: Name HSR-FRICO Number 13-15 Effective Date: \_\_\_\_\_

To: Name \_\_\_\_\_ Number \_\_\_\_\_

☐ **ABANDON PERMIT: Permit can only be abandoned if the permitted operation has NOT been conducted. Field inspection will be conducted to verify site status.**

☐ WELL: Abandon Application for Permit-to-Drill (Form2) – Well API Number \_\_\_\_\_ has not been drilled.

☐ PIT: Abandon Earthen Pit Permit (Form 15) – COGCC Pit Facility ID Number \_\_\_\_\_ has not been constructed (Permitted and constructed pit requires closure per Rule 905)

☐ CENTRALIZED E&P WASTE MANAGEMENT FACILITY: Abandon Centralized E&P Waste Management Facility Permit (Form 28) – Facility ID Number \_\_\_\_\_ has not been constructed (Constructed facility requires closure per Rule 908)

OIL & GAS LOCATION ID Number: \_\_\_\_\_

☐ Abandon Oil & Gas Location Assessment (Form 2A) – Location has not been constructed and site will not be used in the future.

☐ Keep Oil & Gas Location Assessment (Form 2A) active until expiration date. This site will be used in the future.

**Surface disturbance from Oil and Gas Operations must be reclaimed per Rule 1003 and Rule 1004.**

☐ **REQUEST FOR CONFIDENTIAL STATUS**

☐ **DIGITAL WELL LOG UPLOAD**

☐ **DOCUMENTS SUBMITTED** Purpose of Submission: \_\_\_\_\_

**RECLAMATION****INTERIM RECLAMATION**

☐ Interim Reclamation will commence approximately \_\_\_\_\_

Per Rule 1003.e.(3) operator shall submit Sundry Notice reporting interim reclamation is complete and site is ready for inspection when vegetation reaches 80% coverage.

☐ Interim reclamation complete, site ready for inspection.

Per Rule 1003.e(3) describe interim reclamation procedure in Comments below or provide as an attachment and attach required location photographs.

**Field inspection will be conducted to document Rule 1003.e. compliance**

**FINAL RECLAMATION**

☐ Final Reclamation will commence approximately \_\_\_\_\_

Per Rule 1004.c.(4) operator shall submit Sundry Notice reporting final reclamation is complete and site is ready for inspection when vegetation reaches 80% coverage.

☐ Final reclamation complete, site ready for inspection. Per Rule 1004.c(4) describe final reclamation procedure in Comments below or provide as an attachment.

**Field inspection will be conducted to document Rule 1004.c. compliance**

Comments:

#### ENGINEERING AND ENVIRONMENTAL WORK

##### ☐ NOTICE OF CONTINUED TEMPORARILY ABANDONED STATUS

Indicate why the well is temporarily abandoned and describe future plans for utilization in the COMMENTS box below or provide as an attachment, as required by Rule 319.b.(3).

Date well temporarily abandoned \_\_\_\_\_ Has Production Equipment been removed from site? \_\_\_\_\_

Mechanical Integrity Test (MIT) required if shut in longer than 2 years. Date of last MIT \_\_\_\_\_

☐ SPUD DATE: \_\_\_\_\_

#### TECHNICAL ENGINEERING AND ENVIRONMENTAL WORK

Details of work must be described in full in the COMMENTS below or provided as an attachment.

☒ NOTICE OF INTENT Approximate Start Date 10/30/2014

☐ REPORT OF WORK DONE Date Work Completed \_\_\_\_\_

- |  |   |  |
|--|---|--|
| <input type="checkbox"/> Intent to Recomplete (Form 2 also required) | <input type="checkbox"/> Request to Vent or Flare   | <input type="checkbox"/> E&P Waste Mangement Plan      |
| <input type="checkbox"/> Change Drilling Plan                        | <input checked="" type="checkbox"/> Repair Well   | <input type="checkbox"/> Beneficial Reuse of E&P Waste |
| <input type="checkbox"/> Gross Interval Change                       | <input type="checkbox"/> Rule 502 variance requested. Must provide detailed info regarding request. |  |
| <input type="checkbox"/> Other _____                                 | <input type="checkbox"/> Status Update/Change of Remediation Plans for Spills and Releases          |  |

#### COMMENTS:

- 1) MIRU Workover rig, pump & tank.
- 2) Control well with kill fluid.
- 3) POOH 2 3/8" tubing.
- 4) RIH w/ Bit & Scraper. Tag fill if any. Clean out to PBTD (talley in). TOOH.
- 5) RIH w/ RBP. Set RBP @ approx 6790'. Spot 2 sx sand on top of RBP. Test RBP 2000 psi. TOOH.
- 6) Bleed off bradenhead, unland casing.
- 7) RIH 1 1/4" tubing down annulus w/ mule shoe to approx. 1250'. Condition hole.
- 8) RU cement crew, pump 352 sx cement w/ gas check, bringing cement to approx 678'
- 9) POOH w/ 1 1/4" tubing to 728'. Reverse circulate out until no returns of cement at surface.
- 10) POOH w/ 1 1/4" tubing. Re-land casing.
- 11) SI well & WOC (at least 4 hours, but preferably overnight). Run CBL, recording new cement depths.
- 12) Clean out hole. Retrieve RBP
- 13) Hydro test in 2 3/8" tubing, seat nipple, and notched collar. Seat nipple set depth of 7089' (same as before).
- 14) RDMO.

#### CASING AND CEMENTING CHANGES

Casing Type	Size	Of	/	Hole	Size	Of	/	Casing	Wt/Ft	Csg/LinTop	Setting Depth	Sacks of Cement	Cement Bottom	Cement Top

#### H2S REPORTING

Data Fields in this section are intended to document Sample and Location Data associated with the collection of a Gas Sample that is submitted for Laboratory Analysis.

Gas Analysis Report must be attached.

H2S Concentration: \_\_\_\_\_ in ppm (parts per million) Date of Measurement or Sample Collection \_\_\_\_\_

Description of Sample Point:

Absolute Open Flow Potential \_\_\_\_\_ in CFPD (cubic feet per day)

Description of Release Potential and Duration (If flow is not open to the atmosphere, identify the duration in which the container or pipeline would likely be opened for servicing operations.):

Distance to nearest occupied residence, school, church, park, school bus stop, place of business, or other areas where the public could reasonably be expected to frequent: \_\_\_\_\_

Distance to nearest Federal, State, County, or municipal road or highway owned and principally maintained for public use: \_\_\_\_\_

COMMENTS:

**Best Management Practices**

<b><u>No</u></b>		<b><u>BMP/COA Type</u></b>	<b><u>Description</u></b>

Operator Comments:

--

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: KATHLEEN MILLS

Title: REGULATORY ANALYST Email: kmills@nobleenergyinc.com Date: \_\_\_\_\_

Based on the information provided herein, this Sundry Notice (Form 4) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_

**CONDITIONS OF APPROVAL, IF ANY:**

**General Comments**

<b><u>User Group</u></b>	<b><u>Comment</u></b>	<b><u>Comment Date</u></b>
--------------------------	-----------------------	----------------------------

--	--	--

Total: 0 comment(s)

**Attachment Check List**

<b><u>Att Doc Num</u></b>	<b><u>Name</u></b>
---------------------------	--------------------

--	--

Total Attach: 0 Files