

FORM
6Rev
12/05

State of Colorado

Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
----	----	----	----

Document Number:

400725347

Date Received:

11/06/2014

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 100322

Contact Name: Jeremy Gilbert

Name of Operator: NOBLE ENERGY INC

Phone: (720) 587-2290

Address: 1625 BROADWAY STE 2200

Fax: (970) 304-5099

City: DENVER State: CO Zip: 80202

Email: Jgilbert@nobleenergyinc.com

For "Intent" 24 hour notice required,

Name: Gomez, Jason

Tel: (970) 573-1277

COGCC contact:

Email: jason.gomez@state.co.us

API Number 05-123-13270-00

Well Name: PEPPLER

Well Number: 1-36

Location: QtrQtr: SWSW Section: 36 Township: 5N Range: 66W Meridian: 6

County: WELD

Federal, Indian or State Lease Number: 56005

Field Name: WATTENBERG

Field Number: 90750

☒ Notice of Intent to Abandon☐ Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.350190

Longitude: -104.733390

GPS Data:

Date of Measurement: 10/11/2007

PDOP Reading: 2.4

GPS Instrument Operator's Name: Cody Mattson

Reason for Abandonment:

☐ Dry☒ Production for Sub-economic☐ Mechanical Problems☐ Other

Casing to be pulled:

☒ Yes☐ No

Estimated Depth: 4500

Fish in Hole:

☐ Yes☐ No

If yes, explain details below

Wellbore has Uncemented Casing leaks:

☐ Yes☐ No

If yes, explain details below

Details:

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	7140	7157	11/25/2013	BRIDGE PLUG	

Total: 1 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	515	360	515	0	VISU
1ST	7+7/8	4+1/2	11.6	7,280	230	7,280	6,200	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7090 with 2 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 100 sks cmt from 4550 ft. to 4350 ft. Plug Type: STUB PLUG Plug Tagged: ☐
Set 50 sks cmt from 2500 ft. to 2400 ft. Plug Type: CASING Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 220 sacks half in. half out surface casing from 565 ft. to 0 ft. Plug Tagged: ☒

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No *ATTACH JOB SUMMARY

Technical Detail/Comments:

Note: Tag RBP @6303', dump bail 2sx of cement on Top. If RBP is not set RIH w/CIBP.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Marilyn Tucker

Title: Engineering Tech Date: 11/6/2014 Email: mtucker@nobleenergyinc.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: JENKINS, STEVE Date: 11/14/2014

CONDITIONS OF APPROVAL, IF ANY: _____

Expiration Date: 5/13/2015

COA Type	Description
	<p>Note changes to plugging procedure:</p> <p>1) Provide 48 hour notice of plugging MIRU via electronic Form 42.</p> <p>2) Install CIBP at 7040 instead of 7000.</p> <p>3) For 4550' plug: pump plug and displace. If casing plug is not circulated to surface then tag plug – must be 4350' or shallower.</p> <p>4) For 565' plug: pump plug and displace. If surface casing plug is not circulated to surface then tag plug – must be 465' or shallower and provide 10 sx plug at the surface. Leave at least 100' cement in the casing for each plug.</p> <p>5) Properly abandon flowlines as per Rule 1103. File electronic Form 42 once abandonment complete.</p>

Attachment Check List

Att Doc Num	Name
400725347	FORM 6 INTENT SUBMITTED
400725380	WELLBORE DIAGRAM
400725382	WELLBORE DIAGRAM
400725383	PROPOSED PLUGGING PROCEDURE

Total Attach: 4 Files

General Comments

User Group	Comment	Comment Date
Permit	Well Completion Report dated 2/27/1987.	11/13/2014 3:36:37 PM

Total: 1 comment(s)