

**State of Colorado**  
**Oil and Gas Conservation Commission**

1120 Lincoln Street, Suite 801, Denver, Colorado 80203  
Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
Document Number: <b>400736943</b>			
Date Received: <b>11/19/2014</b>			

**SUNDRY NOTICE**

Submit a signed original. This form is to be used for general, technical and environmental sundry information. For proposed or completed operations, describe in full in Comments or provide as an attachment. Identify Well by API Number; identify Oil and Gas Location by Location ID Number; identify other Facility by Facility ID Number.

OGCC Operator Number: 47120 Contact Name Cheryl Light  
Name of Operator: KERR MCGEE OIL & GAS ONSHORE LP Phone: (720) 929-6461  
Address: P O BOX 173779 Fax: (720) 929-7461  
City: DENVER State: CO Zip: 80217-3779 Email: cheryl.light@anadarko.com

Complete the Attachment  
Checklist

OP OGCC

API Number : 05- 123 17025 00 OGCC Facility ID Number: 249223  
Well/Facility Name: HSR-SPILMAN Well/Facility Number: 9-35  
Location QtrQtr: NESE Section: 35 Township: 4N Range: 66W Meridian: 6  
County: WELD Field Name: WATTENBERG  
Federal, Indian or State Lease Number: \_\_\_\_\_

Survey Plat		
Directional Survey		
Srvc Eqpmt Diagram		
Technical Info Page		
Other		

**CHANGE OF LOCATION OR AS BUILT GPS REPORT**

- ☐ Change of Location \* ☐ As-Built GPS Location Report ☐ As-Built GPS Location Report with Survey

\* Well location change requires new plat. A substantive surface location change may require new Form 2A.

**SURFACE LOCATION GPS DATA** Data must be provided for Change of Surface Location and As Built Reports.

Latitude \_\_\_\_\_ PDOP Reading \_\_\_\_\_ Date of Measurement \_\_\_\_\_  
Longitude \_\_\_\_\_ GPS Instrument Operator's Name \_\_\_\_\_

**LOCATION CHANGE (all measurements in Feet)**

Well will be: \_\_\_\_\_ (Vertical, Directional, Horizontal)

Change of **Surface** Footage **From** Exterior Section Lines:

Change of **Surface** Footage **To** Exterior Section Lines:

Current **Surface** Location **From** QtrQtr NESE Sec 35

New **Surface** Location **To** QtrQtr \_\_\_\_\_ Sec \_\_\_\_\_

Change of **Top of Productive Zone** Footage **From** Exterior Section Lines:

Change of **Top of Productive Zone** Footage **To** Exterior Section Lines:

Current **Top of Productive Zone** Location **From** Sec \_\_\_\_\_

New **Top of Productive Zone** Location **To** Sec \_\_\_\_\_

Change of **Bottomhole** Footage **From** Exterior Section Lines:

Change of **Bottomhole** Footage **To** Exterior Section Lines:

Current **Bottomhole** Location Sec \_\_\_\_\_ Twp \_\_\_\_\_

New **Bottomhole** Location Sec \_\_\_\_\_ Twp \_\_\_\_\_

Is location in High Density Area? \_\_\_\_\_

Distance, in feet, to nearest building \_\_\_\_\_, public road: \_\_\_\_\_, above ground utility: \_\_\_\_\_, railroad: \_\_\_\_\_,

property line: \_\_\_\_\_, lease line: \_\_\_\_\_, well in same formation: \_\_\_\_\_

Ground Elevation \_\_\_\_\_ feet Surface owner consultation date \_\_\_\_\_

FNL/FSL		FEL/FWL	
2006	FSL	670	FEL
Twp <u>4N</u>	Range <u>66W</u>	Meridian <u>6</u>	
Twp _____	Range _____	Meridian _____	
			**
Twp _____	Range _____		
Twp _____	Range _____		
			**

\*\* attach deviated drilling plan

**CHANGE OR ADD OBJECTIVE FORMATION AND/OR SPACING UNIT**

<u>Objective Formation</u>	<u>Formation Code</u>	<u>Spacing Order Number</u>	<u>Unit Acreage</u>	<u>Unit Configuration</u>

**OTHER CHANGES**

☐ **REMOVE FROM SURFACE BOND** Signed surface use agreement is a required attachment

☐ **CHANGE OF WELL, FACILITY OR OIL & GAS LOCATION NAME OR NUMBER**

From: Name HSR-SPILMAN Number 9-35 Effective Date: \_\_\_\_\_

To: Name \_\_\_\_\_ Number \_\_\_\_\_

☐ **ABANDON PERMIT: Permit can only be abandoned if the permitted operation has NOT been conducted. Field inspection will be conducted to verify site status.**

☐ WELL: Abandon Application for Permit-to-Drill (Form2) – Well API Number \_\_\_\_\_ has not been drilled.

☐ PIT: Abandon Earthen Pit Permit (Form 15) – COGCC Pit Facility ID Number \_\_\_\_\_ has not been constructed (Permitted and constructed pit requires closure per Rule 905)

☐ CENTRALIZED E&P WASTE MANAGEMENT FACILITY: Abandon Centralized E&P Waste Management Facility Permit (Form 28) – Facility ID Number \_\_\_\_\_ has not been constructed (Constructed facility requires closure per Rule 908)

OIL & GAS LOCATION ID Number: \_\_\_\_\_

☐ Abandon Oil & Gas Location Assessment (Form 2A) – Location has not been constructed and site will not be used in the future.

☐ Keep Oil & Gas Location Assessment (Form 2A) active until expiration date. This site will be used in the future.

**Surface disturbance from Oil and Gas Operations must be reclaimed per Rule 1003 and Rule 1004.**

☐ **REQUEST FOR CONFIDENTIAL STATUS**

☐ **DIGITAL WELL LOG UPLOAD**

☐ **DOCUMENTS SUBMITTED** Purpose of Submission: \_\_\_\_\_

**RECLAMATION****INTERIM RECLAMATION**

☐ Interim Reclamation will commence approximately \_\_\_\_\_

Per Rule 1003.e.(3) operator shall submit Sundry Notice reporting interim reclamation is complete and site is ready for inspection when vegetation reaches 80% coverage.

☐ Interim reclamation complete, site ready for inspection.

Per Rule 1003.e(3) describe interim reclamation procedure in Comments below or provide as an attachment and attach required location photographs.

**Field inspection will be conducted to document Rule 1003.e. compliance**

**FINAL RECLAMATION**

☐ Final Reclamation will commence approximately \_\_\_\_\_

Per Rule 1004.c.(4) operator shall submit Sundry Notice reporting final reclamation is complete and site is ready for inspection when vegetation reaches 80% coverage.

☐ Final reclamation complete, site ready for inspection. Per Rule 1004.c(4) describe final reclamation procedure in Comments below or provide as an attachment.

**Field inspection will be conducted to document Rule 1004.c. compliance**

Comments:

**ENGINEERING AND ENVIRONMENTAL WORK**

☐ NOTICE OF CONTINUED TEMPORARILY ABANDONED STATUS

Indicate why the well is temporarily abandoned and describe future plans for utilization in the COMMENTS box below or provide as an attachment, as required by Rule 319.b.(3).

Date well temporarily abandoned \_\_\_\_\_ Has Production Equipment been removed from site? \_\_\_\_\_

Mechanical Integrity Test (MIT) required if shut in longer than 2 years. Date of last MIT \_\_\_\_\_

☐ SPUD DATE: \_\_\_\_\_

**TECHNICAL ENGINEERING AND ENVIRONMENTAL WORK**

Details of work must be described in full in the COMMENTS below or provided as an attachment.

☒ NOTICE OF INTENT Approximate Start Date 12/03/2014

☐ REPORT OF WORK DONE Date Work Completed \_\_\_\_\_

- |  |   |  |
|--|---|--|
| <input type="checkbox"/> Intent to Recomplete (Form 2 also required) | <input type="checkbox"/> Request to Vent or Flare   | <input type="checkbox"/> E&P Waste Mangement Plan      |
| <input type="checkbox"/> Change Drilling Plan                        | <input checked="" type="checkbox"/> Repair Well   | <input type="checkbox"/> Beneficial Reuse of E&P Waste |
| <input type="checkbox"/> Gross Interval Change                       | <input type="checkbox"/> Rule 502 variance requested. Must provide detailed info regarding request. |  |
| <input type="checkbox"/> Other _____                                 | <input type="checkbox"/> Status Update/Change of Remediation Plans for Spills and Releases          |  |

**COMMENTS:**

1 MIRU Wireline services. PU and RIH w/ CCL-CBL-VDL tools and log from 5000' to surface. Email logs to Jacob.Barker@Anadarko.com – call if there is cement behind casing above 3,500'. Email copies of logs, summaries and invoices to rscDJVendors@Anadarko.com within 24hrs.

2 ND BOP. Unland production casing (4-1/2", 11.6#, I-70), ND surface casing head and NU double entry flange. 1993 vintage casing, don't pull with more than 100,000lbs (50% of virgin joint strength).

3 Pick up concentrated mud flush (Alcomer 74L – liquid mud thinner in 5 gallon bucket) from Imperial.

4 Pick Up 49 jnts of TBG (1-1/4", 2.33#, J-55, IJ). Run in annulus with pup jnt with CutRight, burn shoe or mule shoe on 1-1/4" tbg to 1500' or as deep as possible while circulating. Circulate mud flush sweeps intermittently (about 2 or 3 while TIH). If TBG hits tight spots work it for a bit while circulating to break the bridge as best possible. Call engineering if there is difficulty making depth or if a power swivel is necessary to break bridging.

5 Once EOT of 1-1/4" is at 1500' circulate another 4 hours minimum using at least 1 mud flush sweep.

6 Order and pump 15 bbls of 10# mud from Imperial. Displace with 2 bbl of fresh water to prevent unbalanced flow back. Note: Don't put mud in tanks contaminated with mud flush.

7 Pull 1-1/4" TBG up annulus so EOT at +/- 1,300'.

8 MIRU cementing services.

9 Mix & pump as follows: 5 bbls fresh water, 10 bbls Sodium Metasilicate (SMS), 10 bbl fresh water spacer, 365 sks Type III cement, 1/4#/sk Cello Flake, mixed at 14.8 ppg and yield of 1.33 cuft/sk (retardant amounts as determined by cementing service company for a 3 hour pumping time at 80° F) for a total of 86.5 bbl of cement. Design is for coverage from 1300' to 430' in 10" Borehole and 106' in 8.1" with a 20% excess (has caliper log). See Calculation if necessary. Don't displace with any fresh water.

10 POOH with 1-1/4" tbg to +/- 300 and circulate back to tanks until clean.

11 POOH and SB tbg. ND double entry flange and Re-Land the 4-1/2" production casing immediately.

12 NU tubing head, be sure it is a 5,000 psi rated unit. NU BOP.

13 Shut in and WOC for 24 hrs minimum and at least 30 hrs before pressure testing back side of packer.

14 MIRU Wireline services. PU and RIH w/ CCL-CBL-VDL tools and log from 1400' to surface. NOTE: IF TOC IS BELOW 390' OR POOR BOND, CONTACT EVANS ENGINEERING. Email logs to Jacob.Barker@Anadarko.com. Email copies of logs, summaries and invoices to rscDJVendors@Anadarko.com within 24hrs.

15 POOH, RDMO Wireline service company.

**CASING AND CEMENTING CHANGES**

Casing Type	Size	Of	/	Hole	Size	Of	/	Casing	Wt/Ft	Csg/LinTop	Setting Depth	Sacks of Cement	Cement Bottom	Cement Top

## H2S REPORTING

Data Fields in this section are intended to document Sample and Location Data associated with the collection of a Gas Sample that is submitted for Laboratory Analysis.

Gas Analysis Report must be attached.

H2S Concentration: \_\_\_\_\_ in ppm (parts per million)

Date of Measurement or Sample Collection \_\_\_\_\_

Description of Sample Point:

--

Absolute Open Flow Potential \_\_\_\_\_ in CFPD (cubic feet per day)

Description of Release Potential and Duration (If flow is not open to the atmosphere, identify the duration in which the container or pipeline would likely be opened for servicing operations.):

--

Distance to nearest occupied residence, school, church, park, school bus stop, place of business, or other areas where the public could reasonably be expected to frequent: \_\_\_\_\_

Distance to nearest Federal, State, County, or municipal road or highway owned and principally maintained for public use: \_\_\_\_\_

COMMENTS:

--

## Best Management Practices

No BMP/COA Type

Description

--	--

**Operator Comments:**

--

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Cheryl Light  
Title: Sr. Regulatory Analyst Email: DJRegulatory@anadarko.com Date: 11/19/2014

Based on the information provided herein, this Sundry Notice (Form 4) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: JENKINS, STEVE Date: 11/21/2014

**CONDITIONS OF APPROVAL, IF ANY:****COA Type****Description**

	Submit the CBL to the COGCC when available.
--	---

**General Comments****User Group****Comment****Comment Date**

--	--	--

Total: 0 comment(s)

**Attachment Check List****Att Doc Num****Name**

400736943	FORM 4 SUBMITTED
400736945	OTHER

Total Attach: 2 Files