

DE	ET	OE	ES
----	----	----	----

**Replug By Other Operator**

Document Number:  
400817878

Date Received:

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 100322 Contact Name: Hunter Dunham  
 Name of Operator: NOBLE ENERGY INC Phone: (303) 228-4308  
 Address: 1625 BROADWAY STE 2200 Fax: (303) 228-4286  
 City: DENVER State: CO Zip: 80202 Email: hdunham@nobleenergyinc.com

**For "Intent" 24 hour notice required,** Name: Gomez, Jason Tel: (970) 573-1277  
**COGCC contact:** Email: jason.gomez@state.co.us

API Number 05-123-14077-00  
 Well Name: Federal Perry Well Number: 8-30  
 Location: QtrQtr: SENE Section: 30 Township: 9N Range: 58W Meridian: 6  
 County: WELD Federal, Indian or State Lease Number: C36880  
 Field Name: WILDCAT Field Number: 99999

Notice of Intent to Abandon  Subsequent Report of Abandonment

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 40.723790 Longitude: -103.899890  
 GPS Data:  
 Date of Measurement: 07/23/2013 PDOP Reading: 1.8 GPS Instrument Operator's Name: Brian Rottinghaus  
 Reason for Abandonment:  Dry  Production for Sub-economic  Mechanical Problems  
 Other \_\_\_\_\_  
 Casing to be pulled:  Yes  No Estimated Depth: \_\_\_\_\_  
 Fish in Hole:  Yes  No If yes, explain details below  
 Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below  
 Details: \_\_\_\_\_

**Current and Previously Abandoned Zones**

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
J SAND	6648		07/23/2013	CEMENT	6177
Total: 1 zone(s)					

**Casing History**

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	256	100	256	0	VISU

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 215 sks cmt from 6117 ft. to 5898 ft. Plug Type: OPEN HOLE Plug Tagged:   
Set 750 sks cmt from 3033 ft. to 2847 ft. Plug Type: OPEN HOLE Plug Tagged:   
Set 250 sks cmt from 1345 ft. to 363 ft. Plug Type: OPEN HOLE Plug Tagged:   
Set 115 sks cmt from 363 ft. to 0 ft. Plug Type: CASING Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
(Cast Iron Cement Retainer Depth)  
Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged:   
Set \_\_\_\_\_ sacks at surface  
Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No  
Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: 07/23/2013  
\*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: BAKER HUGHES  
Type of Cement and Additives Used: \_\_\_\_\_  
Flowline/Pipeline has been abandoned per Rule 1103  Yes  No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Eileen Roberts  
Title: Regulatory Analyst I Date: \_\_\_\_\_ Email: eroberts@nobleenergyinc.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_

**CONDITIONS OF APPROVAL, IF ANY:**

\_\_\_\_\_

## Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
400818005	CEMENT JOB SUMMARY
400818006	CEMENT JOB SUMMARY
400818007	CEMENT JOB SUMMARY
400818008	WELLBORE DIAGRAM
400818010	WELLBORE DIAGRAM
400818014	PROPOSED PLUGGING PROCEDURE

Total Attach: 6 Files

## General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>

Total: 0 comment(s)