



WORKOVER PROCEDURE

PROJECT: RTI FU #3
AFE#: NA AMOUNT: NA
DATE: 4/20/15 ENGINEER: Lee Lanehart

Current Perforation	5,166'-5,179'
---------------------	---------------

PROCEDURE

1. MIRU Hot Oiler
2. Hook up to casing, load and pressure test to 500# for 15 min
 - a. If pass pressure test go to step 3
 - b. If fails call engineer and discuss option.
3. RD MO Hot oiler
4. Tie into injection line at section 7 battery
5. Start gas injection 115 MCFD section 7 gas
 - a. Gas from FU1, FU2 & FU4
6. Monitor pressure and rate for 7 days