

**State of Colorado**  
**Oil and Gas Conservation Commission**

1120 Lincoln Street, Suite 801, Denver, Colorado 80203  
Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
Document Number: <b>400831584</b>			
Date Received: <b>04/28/2015</b>			

**SUNDRY NOTICE**

Submit a signed original. This form is to be used for general, technical and environmental sundry information. For proposed or completed operations, describe in full in Comments or provide as an attachment. Identify Well by API Number; identify Oil and Gas Location by Location ID Number; identify other Facility by Facility ID Number.

OGCC Operator Number: <u>47120</u>	Contact Name <u>Cheryl Light</u>
Name of Operator: <u>KERR MCGEE OIL &amp; GAS ONSHORE LP</u>	Phone: <u>(720) 929-6461</u>
Address: <u>P O BOX 173779</u>	Fax: <u>(720) 929-7461</u>
City: <u>DENVER</u> State: <u>CO</u> Zip: <u>80217-3779</u>	Email: <u>cheryl.light@anadarko.com</u>

Complete the Attachment  
Checklist

OP OGCC

API Number : 05- <u>123 22587 00</u>	OGCC Facility ID Number: <u>274854</u>
Well/Facility Name: <u>CANNON LAND</u>	Well/Facility Number: <u>7-33</u>
Location QtrQtr: <u>SWNE</u> Section: <u>33</u> Township: <u>3N</u> Range: <u>65W</u> Meridian: <u>6</u>	
County: <u>WELD</u> Field Name: <u>WATTENBERG</u>	
Federal, Indian or State Lease Number: _____	

Survey Plat		
Directional Survey		
Srvc Eqpmt Diagram		
Technical Info Page		
Other		

**CHANGE OF LOCATION OR AS BUILT GPS REPORT**

☐ Change of Location \* ☐ As-Built GPS Location Report ☐ As-Built GPS Location Report with Survey

\* Well location change requires new plat. A substantive surface location change may require new Form 2A.

**SURFACE LOCATION GPS DATA** Data must be provided for Change of Surface Location and As Built Reports.

Latitude \_\_\_\_\_ PDOP Reading \_\_\_\_\_ Date of Measurement \_\_\_\_\_  
Longitude \_\_\_\_\_ GPS Instrument Operator's Name \_\_\_\_\_

**LOCATION CHANGE (all measurements in Feet)**

Well will be: \_\_\_\_\_ (Vertical, Directional, Horizontal)

Change of **Surface** Footage **From** Exterior Section Lines:

Change of **Surface** Footage **To** Exterior Section Lines:

Current **Surface** Location **From** QtrQtr SWNE Sec 33

New **Surface** Location **To** QtrQtr \_\_\_\_\_ Sec \_\_\_\_\_

Change of **Top of Productive Zone** Footage **From** Exterior Section Lines:

Change of **Top of Productive Zone** Footage **To** Exterior Section Lines:

Current **Top of Productive Zone** Location **From** Sec \_\_\_\_\_

New **Top of Productive Zone** Location **To** Sec \_\_\_\_\_

Change of **Bottomhole** Footage **From** Exterior Section Lines:

Change of **Bottomhole** Footage **To** Exterior Section Lines:

Current **Bottomhole** Location Sec \_\_\_\_\_ Twp \_\_\_\_\_

New **Bottomhole** Location Sec \_\_\_\_\_ Twp \_\_\_\_\_

Is location in High Density Area? \_\_\_\_\_

Distance, in feet, to nearest building \_\_\_\_\_, public road: \_\_\_\_\_, above ground utility: \_\_\_\_\_, railroad: \_\_\_\_\_,

property line: \_\_\_\_\_, lease line: \_\_\_\_\_, well in same formation: \_\_\_\_\_

Ground Elevation \_\_\_\_\_ feet Surface owner consultation date \_\_\_\_\_

FNL/FSL		FEL/FWL	
1920	FNL	2122	FEL
Twp <u>3N</u>	Range <u>65W</u>	Meridian <u>6</u>	
Twp _____	Range _____	Meridian _____	
			**
			**
			** attach deviated drilling plan

**CHANGE OR ADD OBJECTIVE FORMATION AND/OR SPACING UNIT**

<u>Objective Formation</u>	<u>Formation Code</u>	<u>Spacing Order Number</u>	<u>Unit Acreage</u>	<u>Unit Configuration</u>

**OTHER CHANGES**

☐ **REMOVE FROM SURFACE BOND** Signed surface use agreement is a required attachment

☐ **CHANGE OF WELL, FACILITY OR OIL & GAS LOCATION NAME OR NUMBER**

From: Name CANNON LAND Number 7-33 Effective Date: \_\_\_\_\_

To: Name \_\_\_\_\_ Number \_\_\_\_\_

☐ **ABANDON PERMIT: Permit can only be abandoned if the permitted operation has NOT been conducted. Field inspection will be conducted to verify site status.**

☐ WELL: Abandon Application for Permit-to-Drill (Form2) – Well API Number \_\_\_\_\_ has not been drilled.

☐ PIT: Abandon Earthen Pit Permit (Form 15) – COGCC Pit Facility ID Number \_\_\_\_\_ has not been constructed (Permitted and constructed pit requires closure per Rule 905)

☐ CENTRALIZED E&P WASTE MANAGEMENT FACILITY: Abandon Centralized E&P Waste Management Facility Permit (Form 28) – Facility ID Number \_\_\_\_\_ has not been constructed (Constructed facility requires closure per Rule 908)

OIL & GAS LOCATION ID Number: \_\_\_\_\_

☐ Abandon Oil & Gas Location Assessment (Form 2A) – Location has not been constructed and site will not be used in the future.

☐ Keep Oil & Gas Location Assessment (Form 2A) active until expiration date. This site will be used in the future.

**Surface disturbance from Oil and Gas Operations must be reclaimed per Rule 1003 and Rule 1004.**

☐ **REQUEST FOR CONFIDENTIAL STATUS**

☐ **DIGITAL WELL LOG UPLOAD**

☐ **DOCUMENTS SUBMITTED** Purpose of Submission: \_\_\_\_\_

**RECLAMATION****INTERIM RECLAMATION**

☐ Interim Reclamation will commence approximately \_\_\_\_\_

Per Rule 1003.e.(3) operator shall submit Sundry Notice reporting interim reclamation is complete and site is ready for inspection when vegetation reaches 80% coverage.

☐ Interim reclamation complete, site ready for inspection.

Per Rule 1003.e(3) describe interim reclamation procedure in Comments below or provide as an attachment and attach required location photographs.

**Field inspection will be conducted to document Rule 1003.e. compliance**

**FINAL RECLAMATION**

☐ Final Reclamation will commence approximately \_\_\_\_\_

Per Rule 1004.c.(4) operator shall submit Sundry Notice reporting final reclamation is complete and site is ready for inspection when vegetation reaches 80% coverage.

☐ Final reclamation complete, site ready for inspection. Per Rule 1004.c(4) describe final reclamation procedure in Comments below or provide as an attachment.

**Field inspection will be conducted to document Rule 1004.c. compliance**

Comments:

## ENGINEERING AND ENVIRONMENTAL WORK

### ☐ NOTICE OF CONTINUED TEMPORARILY ABANDONED STATUS

Indicate why the well is temporarily abandoned and describe future plans for utilization in the COMMENTS box below or provide as an attachment, as required by Rule 319.b.(3).

Date well temporarily abandoned \_\_\_\_\_ Has Production Equipment been removed from site? \_\_\_\_\_

Mechanical Integrity Test (MIT) required if shut in longer than 2 years. Date of last MIT \_\_\_\_\_

☐ SPUD DATE: \_\_\_\_\_

## TECHNICAL ENGINEERING AND ENVIRONMENTAL WORK

Details of work must be described in full in the COMMENTS below or provided as an attachment.

☒ NOTICE OF INTENT Approximate Start Date 05/12/2015

☐ REPORT OF WORK DONE Date Work Completed \_\_\_\_\_

- |  |   |  |
|--|---|--|
| <input type="checkbox"/> Intent to Recomplete (Form 2 also required) | <input type="checkbox"/> Request to Vent or Flare   | <input type="checkbox"/> E&P Waste Management Plan     |
| <input type="checkbox"/> Change Drilling Plan                        | <input checked="" type="checkbox"/> Repair Well   | <input type="checkbox"/> Beneficial Reuse of E&P Waste |
| <input type="checkbox"/> Gross Interval Change                       | <input type="checkbox"/> Rule 502 variance requested. Must provide detailed info regarding request. |  |
| <input type="checkbox"/> Other _____                                 | <input type="checkbox"/> Status Update/Change of Remediation Plans for Spills and Releases          |  |

## COMMENTS:

1 Well needs single stage annular fill from 1360' to 515' due to Bradenhead pressure and fluid flow.  
2 Well has gyro 12/30/14  
3 Call Automation Removal Group 24 hours before rig up to isolate any production equipment (remove plunger, wellhead automation, etc.). Prepare to move base beam rig onto location. Install fence if needed.  
4 Check and report surface casing pressure. If valve is not accessible at ground level, re-plumb so valve is at ground level.  
5 MIRU slickline. RIH to retrieve production equipment and tag for fill. Note tagged depth in OpenWells. RDMO slickline.  
6 MIRU WO rig. Spot 1500' of 1.66" 2.33 J-55 10RD IJ tbg. Kill well as necessary with water and biocide. Attach a hardline from the bradenhead/surface casing valve to a flowback tank and blow down any Bradenhead pressure. (Form 17 was performed 09/25/2012. Bradenhead instantaneous pressure was 110 psi and surfacing casing produced 50 gallons of water during test. Pressure built back up to 61 psi in 15 min). If pressure does not blow down within 1 hour contact engineer, otherwise proceed.  
7 ND wellhead. NU BOP.  
8 PU 8-10' pup joint with TIW valve on top and screw into the tbg hanger. Back out the lock down pins and pull up on the tubing string to break any possible sand bridges. (Do not exceed 80% of tubing tensile strength, or 57,384 lbs.) Unseat and LD the landing joint.  
9 MIRU EMI services. EMI 2-3/8" tbg (232 joints landed at 7174') while TOO H and tally while standing back. Lay down joints that have greater than 35% penetration or wall loss. Replace all joints that fail EMI testing. Document joint numbers and depth of bad tubing and create a Production Equipment Failure report in OpenWells. RDMO EMI services.  
10 PU 10,000 psi rated from above and below RBP (4.5", 11.6#), retrieving head, and 2-3/8" tubing. Set RBP at +/- 6800' (collars located at 6776' and 6819').  
11 Release tbg from RBP and circulate all gas out of the hole. Pumping water with biocide, pressure test RBP and production casing to 1000 psi for 15 minutes. If pressure test passes, proceed; otherwise contact engineering.  
12 Circulate 2 sx of sand on top of RBP and TOO H with 2-3/8" tubing.  
13 ND BOP. ND wellhead. Screw 4-1/2" pup joint into production casing and un-land 4-1/2" production casing. NU double entry flange and BOP. Install 1.66" pipe rams.  
14 PU 1560' of 1.66" 2.33# J-55 10RD IJ tubing and TIH between the 4-1/2" production casing and 8-5/8" surface casing/open hole to +/- 1560'. Circulate with the rig pump while TIH to clean up the annulus. Use two sweeps of Alcomer 74L while TIH and a final sweep at 1560', and circulate until well is dead. Make sure no pressure is present on bradenhead. If gas is detected contact engineering.  
15 Contact Ed Asuchak at 970-515-1170 for mud (min of 24hrs in advance). Pump 20 bbl of 10.0 ppg mud at 1560'. Leave 1.66" tbg full of mud to avoid wet trip and PUH to 1360' to place cement in annulus and LD extra tbg.  
16 MIRU cementing services. Establish circulation and pump 30 bbl (5 bbls of water, 20 bbls of sodium metasilicate, and 5 bbls water) spacer, 400 sx Type III cement with 0.3% CFL-3 + 0.3% CFR-2 + 0.25 lb/sk Polyflake (NO CaCl2) mixed at 14.6ppg 1.12 cuft/sx yield with 3 hour pump time. (based on 9.5" hole size + 20% excess from 1360'-717' and 202' between 8-5/8" 24# surface casing and 4-1/2" 11.6# production casing). Attempt to cement from 1360' to 515'.  
17 TOO H with 1.66" 2.3# J-55 10RD IJ tubing until EOT is at 315' and LD extra tbg. Circulate with freshwater 1.5 times the hole volume or until returns are clean. RDMO cementing services.  
18 TOO H and LD all 1.66" 2.3# J-55 10RD IJ tubing. ND BOP and double entry flange. Use 4-1/2" pup joint to re-land 4-1/2" casing. NU BOP. Install 2-3/8" pipe rams. Shut well in and WOC.

**CASING AND CEMENTING CHANGES**

Casing Type	Size	Of	/	Hole	Size	Of	/	Casing	Wt/Ft	Csg/LinTop	Setting Depth	Sacks of Cement	Cement Bottom	Cement Top

**H2S REPORTING**

**Data Fields in this section are intended to document Sample and Location Data associated with the collection of a Gas Sample that is submitted for Laboratory Analysis.**

**Gas Analysis Report must be attached.**

H2S Concentration: \_\_\_\_\_ in ppm (parts per million)

Date of Measurement or Sample Collection \_\_\_\_\_

Description of Sample Point:

Absolute Open Flow Potential \_\_\_\_\_ in CFPD (cubic feet per day)

Description of Release Potential and Duration (If flow is not open to the atmosphere, identify the duration in which the container or pipeline would likely be opened for servicing operations.):

Distance to nearest occupied residence, school, church, park, school bus stop, place of business, or other areas where the public could reasonably be expected to frequent: \_\_\_\_\_

Distance to nearest Federal, State, County, or municipal road or highway owned and principally maintained for public use: \_\_\_\_\_

COMMENTS:

### **Best Management Practices**

**No BMP/COA Type**

**Description**

--	--

**Operator Comments:**

19 MIRU wireline and run CCL-GR-CBL-VDL from +/- 3600' to surface. If the cement is not at or above 515' contact engineer. RDMO wireline services. In addition to normal handling, of logs/job summaries, email copies of all cement job logs/job summaries and invoices to rscDJVendors@anadarko.com within 24 hrs of the completion of the job.  
20 PU and TIH with retrieving head and 2-3/8" tubing. Circulate sand off of RBP. Latch onto and release RBP at +/- 6800'. TOOH standing back all 2-3/8" tubing and LD RBP.  
21 PU 2-3/8" NC, 2-3/8" XN nipple (be sure nipple is correctly input into OpenWells), and 2-3/8" 4.7# J-55 tbg to surface. Circulate out fill if necessary and land EOT at +/- 7,174' (1 joint above top JSand perms).  
22 RU rig lubricator. Broach tubing to XN seating nipple. RD rig lubricator. ND BOP.  
23 Install 7-1/16" flanged 5000 psi tubing head adaptor with 2-1/16" studded top, 2-1/16" flanged 5000 psi master valve, flanged 5000 psi 2-3/8" plunger lubricator (side outlets threaded). Make sure all wellhead valves are rated to 5,000 psi and all nipples are XXH. Document wellhead components in an OpenWells wellhead report.  
24 Install 2-3/8" pup joint above the master valve. Pressure test the tubing head from below the tubing head through the master valve to 5,000 psi using hydrotester. If wellhead does not pressure test, replace wellhead/ wellhead valves as necessary with 5,000 psi rated equipment.  
25 NU WH. RDMO WO rig. Return well to production team.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Cheryl Light  
Title: Sr. Regulatory Analyst Email: DJRegulatory@anadarko.com Date: 4/28/2015

Based on the information provided herein, this Sundry Notice (Form 4) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: SCHLAGENHAUF, MARK Date: 4/29/2015

**CONDITIONS OF APPROVAL, IF ANY:****COA Type****Description**

- |  |   |
|--|---|
|  | 1) The additional cement referenced shall be placed as indicated and comply with Rule 317.j. The placed cement shall be verified with a CBL and documented with a Form 5 Drilling Completion Report.<br>2) Please submit gyro survey data with Form 5 Drilling Completion Report. |
|--|---|

**General Comments****User Group****Comment****Comment Date**

--	--	--

Total: 0 comment(s)

**Attachment Check List****Att Doc Num****Name**

400831584	FORM 4 SUBMITTED
400831585	OTHER

Total Attach: 2 Files