



The steps for building the fresh water tank pad at the D-17 Pad are as follows:

1. Layout – (measure-placement).
2. Cut in sub-grade.
3. Compact sub-grade.
4. Cut trenches for drainage.
5. Re-compact sub-grade.
6. Haul in sand.
7. Place sand at level grade.
8. Compact sand.
9. Fine grade sand to grade.