

FORM  
6Rev  
12/05State of Colorado  
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

400745999

Date Received:

12/04/2014

## WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 69175

Contact Name: Jenifer Hakkarinen

Name of Operator: PDC ENERGY INC

Phone: (303) 8605800

Address: 1775 SHERMAN STREET - STE 3000

Fax:

City: DENVER State: CO Zip: 80203

Email: Jenifer.Hakkarinen@pdce.com

For "Intent" 24 hour notice required,

Name: Rains, Bill

Tel: (970) 590-6480

COGCC contact:

Email: bill.rains@state.co.us

API Number 05-123-21510-00

Well Name: J&amp;L FARMS

Well Number: 41-29

Location: QtrQtr: NENE Section: 29 Township: 6N Range: 63W Meridian: 6

County: WELD

Federal, Indian or State Lease Number:

Field Name: WATTENBERG

Field Number: 90750

☒ Notice of Intent to Abandon☐ Subsequent Report of Abandonment

## Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.463030

Longitude: -104.453250

GPS Data:

Date of Measurement: 09/29/2008

PDOP Reading: 1.7

GPS Instrument Operator's Name: Holly L. Tracy

Reason for Abandonment:

☐ Dry☒ Production for Sub-economic☐ Mechanical Problems☐ Other

Casing to be pulled:

☒ Yes☐ No

Estimated Depth: 2750

Fish in Hole:

☐ Yes☒ No

If yes, explain details below

Wellbore has Uncemented Casing leaks:

☐ Yes☒ No

If yes, explain details below

Details:

## Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	6749	6757			

Total: 1 zone(s)

## Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	363	200	363	0	
1ST	7	4+1/2	10.5	6,962	400	6,962	2,800	

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6400 with 2 sacks cmt on top. CIBP #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 50 sks cmt from 2700 ft. to 2850 ft. Plug Type: STUB PLUG Plug Tagged: ☒

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 300 sacks half in. half out surface casing from 545 ft. to 0 ft. Plug Tagged: ☒

Set 10 sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_

\*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_

Type of Cement and Additives Used: \_\_\_\_\_

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

Plugging Procedure  
Codell  
Existing Perforations:  
Codell: 6749-6757'  
PBTD: 6962'  
8 5/8" 24# @ 363' W/ 200 sks cmt.  
4.5" 10.5# @ 6962' w/ 140 sks G Cement+260 sks lite cmt (TOC @2800')  
Procedure:  
1)MIRU Workover Rig  
2)Pull production tubing  
3)MIRU wireline  
4)RIH w/CIBP, set @ 6400' (Top of Nio at 6462'), POOH  
5)RIH w/dump bailer and dump 2 sx cement on top of CIBP, POOH  
6)RIH w/casing cutter, cut & pull casing @ ~2750', POOH  
7)TIH set 50 sack plug @ casing stub, ~2700'-2850', POOH  
8)TIH to tag stub plug  
9)TOH and set 300 sack cement plug from 545' to surface  
10)Set 10 sx @ top of surface  
11)Cut casing and weld on cap

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Jenifer Hakkarinen

Title: Regulatory Tech Date: 12/4/2014 Email: Jenifer.Hakkarinen@pdce.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved, MIKE

COGCC Approved:

Date: 12/15/2014

**CONDITIONS OF APPROVAL, IF ANY:**

Expiration Date: 6/14/2015

**COA Type**

**Description**

	1) Submit Form 42 electronically to COGCC 48 hours prior to MIRU. 2) For 545' plug: pump plug and displace. If cement is not circulated to surface, shut-in, WOC 4 hours and tag plug – must be 313' or shallower. Leave at least 100' of cement in the wellbore for each plug. 3) Properly abandon flowlines as per Rule 1103. Once properly abandoned, file electronic form 42. 4) Operator must provide well location GPS coordinates on Subsequent Report of Abandonment in accordance with COGCC As-Built Location Policy and Rule 215.
--	---

**Attachment Check List**

**Att Doc Num**

**Name**

400745999	FORM 6 INTENT SUBMITTED
400746001	WELLBORE DIAGRAM
400746002	WELLBORE DIAGRAM

Total Attach: 3 Files

**General Comments**

**User Group**

**Comment**

**Comment Date**

Permit	Well Completion Report dated 7/25/2003.	12/11/2014 1:22:40 PM
--------	---	--------------------------

Total: 1 comment(s)