

FORM
6
Rev
12/05

State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
Document Number: 401024208			
Date Received: 04/07/2016			

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 100322 Contact Name: John Hatch
 Name of Operator: NOBLE ENERGY INC Phone: (720) 587-2377
 Address: 1625 BROADWAY STE 2200 Fax: _____
 City: DENVER State: CO Zip: 80202 Email: john.hatch@nblenergy.com

For "Intent" 24 hour notice required, Name: Gomez, Jason Tel: (970) 573-1277
COGCC contact: Email: jason.gomez@state.co.us

API Number 05-123-22686-00 Well Number: 6-11
 Well Name: CECIL FARMS
 Location: QtrQtr: NENE Section: 6 Township: 6N Range: 66W Meridian: 6
 County: WELD Federal, Indian or State Lease Number: _____
 Field Name: WATTENBERG Field Number: 90750

Notice of Intent to Abandon Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.521401 Longitude: -104.815874
 GPS Data:
 Date of Measurement: 01/06/2007 PDOP Reading: 4.2 GPS Instrument Operator's Name: David Gipson
 Reason for Abandonment: Dry Production Sub-economic Mechanical Problems
 Other _____
 Casing to be pulled: Yes No Estimated Depth: _____
 Fish in Hole: Yes No If yes, explain details below
 Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below
 Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	7329	7346			
NIOBRARA	7076	7175			
Total: 2 zone(s)					

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	820	575	820	12	VISU
1ST	7+7/8	4+1/2	11.6	7,511	160	7,511	6,420	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7026 with 2 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Perforate and squeeze at 2500 ft. with 95 sacks. Leave at least 100 ft. in casing 2400 CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 380 sacks half in. half out surface casing from 1000 ft. to 0 ft. Plug Tagged:

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1103 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:

Bridgette Lawrence (Halliburton Engineer) 303.513.1199

Perf @1000' to circulate shoe plug up to surface.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Stephanie Dionne

Title: Engineering Tech Date: 4/7/2016 Email: stephanie.dionne@nblenergy.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: HICKEY, MIKE Date: 4/29/2016

CONDITIONS OF APPROVAL, IF ANY: _____ Expiration Date: 10/28/2016

COA Type	Description
	1)Submit Form 42 electronically to COGCC 48 hours prior to MIRU. 2)For 1000' plug: pump plug and displace. Annular cement must be circulated to surface. If production casing cement is not circulated to surface, shut-in, WOC 4 hours and tag plug – must be 770' or shallower and provide minimum 10 sx plug inside and outside at the surface. Leave at least 100' of cement in the wellbore for each plug. 3)Properly abandon flowlines. Once flowlines are properly abandoned, file electronic form 42.

Attachment Check List

Att Doc Num	Name
401024208	FORM 6 INTENT SUBMITTED
401024221	WELLBORE DIAGRAM
401024222	PROPOSED PLUGGING PROCEDURE
401024223	WELLBORE DIAGRAM

Total Attach: 4 Files

General Comments

User Group	Comment	Comment Date
Public Room	Document verification complete 04/11/16	4/11/2016 10:59:54 AM

Total: 1 comment(s)