

Company Name: Energy Search Company

AFE or Project #: _____

API #: 05-001-07229

Well Name/Number: Tsuzuki # 5

Section/Township/Range: SEC 27, T1S, R 67W

Rig #: 30

Tool Pusher: Jose M Navarro

Operator: Mauro Valadez

Rig Hand: Armando Lopez Jr.

Rig Hand: Jose Rivera

Rig Hand: _____

Company Man: Tom Majors

Company Man Cell: 307 752 2539

Today's Date: 4/28/2016

Days on Well: 3

Drive/Hrs	Ride/Hrs	Work/Hrs	Total/Hrs	Per Diem
2		9	11	
2		9	11	
	2	9	11	
	2	9	11	



Task Times:		Job Steps "In Scope"	Task Times:		Job Steps "Out of Bid Scope"
6:00am	7:00am	Crew Travel.	1:00pm	2:00pm	Wait on orders from STATE.
7:00am	7:30am	JSA. Safety meeting, start equipment.			
7:30am	8:30am	Check psi 0' Finish TOOH w/ tbg. LD on FBT 162 jts. total.			
8:30am	10:00am	RU Magna WL RIH w/ CIBP @ 4992' ROH, RIH w/ CDB dump			
		<u>2 sxs of 15.8 # class G cement on top of CIBP @ 4992' ROH.</u>			
10:00am	11:00am	Load up well w/ 60 BBLs, water, pressure up @ 500" for 15			
		Minutes hold pressure good.			
11:00am	1:00pm	WL RIH w/ CBL @ 4700' to surface, good cement RD Magna WL.			
		TIH w/ 50 Jts. Circulate well bore clean get oil out pump 40			
		BBLs, water down csg. Back tbg.			
2:00pm	4:00pm	LD 9 jts. Leave 41jts. On the well @ 1275' establish circulation			
		Mix & pump 50 sxs of 15.8 # class G cement, displace			
		w/ 3 BBLs, water, TOOH w/ 2 3/8 tbg. Stand back 13 stands			
		LD the rest on FBT., Drain cementer, pump, hard line SWI.			
4:00pm	5:00pm	Crew Travel.			
(162 2 3/8 tbg. Total on the well)			Comments:		

P&A Mangers Signature: _____

VP Operations Signiture: _____

Company Name: Energy Search Company
 AFE or Project #: _____
 API #: 05-001-07229
 Well Name/Number: Tsuzuki # 5
 Section/Township/Range: SEC 27, T1S, R 67W
 Rig #: 30
 Tool Pusher: Jose M Navarro
 Operator: Mauro Valadez
 Rig Hand: Armando Lopez Jr.
 Rig Hand: Jose Rivera
 Rig Hand: _____

Company Man: Tom Majors
 Company Man Cell: 307 752 2539

Today's Date: 5/4/2016
 Days on Well: 4

Drive/Hrs	Ride/Hrs	Work/Hrs	Total/Hrs	Per Diem
2		9	11	
2		7	9	
	2	7	9	
	2	7	9	



Task Times:		Job Steps "In Scope"	Task Times:		Job Steps "Out of Bid Scope"
6:00am	7:00am	Crew Travel.			
7:00am	7:30am	JSA. Safety meeting, start equipment.			
7:30am	9:30am	Check psi 0' TIH w/ 2 3/8 tbg. tag cement @ 530' was good,			
9:30am	12:00am	Establish circulation mix & pump 48 sxs of 15.8 # class G			
		Cement to surface, TOO H w/ tbg. LD on FBT.			
12:00pm	2:00pm	Clean tank, hard line, pump, ND B.O.P.s.,			
		RDMO, PU tank & pump, get everthing ready to move.			
		P&A complete.			
2:00pm	3:00pm	Crew Travel.			
Mario went look for new location, to move rig tomorrow.			Comments:		

P&A Mangers Signature: _____ VP Operations Signature: _____