

Recompletion Procedure

UPLRC-George #2

SWSW 1-17S-48W

Kiowa County, CO

1. TOH with rods, pump and tubing.
2. Set CIBP at 5015' to abandon existing Spergen perms at 5034'-5042'.
3. Perforate the St. Louis formation at 4966'-4972' (4spf, 25 holes total).
4. Acidize the St. Louis with 500 gals. 15% MCA and 1000 gals. MOD-202.
5. Swab test.
6. Run tubing, pump and rods. Restore well to production.