

Akers 1

05-017-07204-00

SWSW 6 15S 44W

Cheyenne County, CO

4-1/2" Liner Procedure

1. MIRU workover rig. Pull rods & tubing.
2. Spot 3 cubic feet of sand down well to cover perfs at 4031-37
3. Run 4000' of 4-1/2" 10.5# casing with slim collars
4. RU cementers, pump 100 sx cement, drop wiper plug, displace to TD, WOC
5. Log CBL for TOC
6. Drill out shoe track, circulate sand from perfs
7. Run 2-3/8" completion, return well to production