

# FLOW LINE TEST REPORT

Well Name/Number	Test Date	Line Type	RTest?	Test Time		Pressure		Method	Pass	Fail	Reason for failure	Testor
OSKARSON #114	5/10/17	Flowline poly		Start	715	Start	30	Well Head	✓			M. Jones
				End	735	End	30					
Remarks:												
SAB LINE FROM SEP W/TA SHARED WITH 1034	5/10/17	Steel		Start	739	Start	30	Well Head	✓			M. Jones
				End	755	End	30					
Remarks:												
				Start		Start						
				End		End						
Remarks:												
				Start		Start						
				End		End						
Remarks:												
				Start		Start						
				End		End						
Remarks:												
				Start		Start						
				End		End						
Remarks:												
				Start		Start						
				End		End						
Remarks:												
				Start		Start						
				End		End						
Remarks:												
				Start		Start						
				End		End						
Remarks:												

Line Types: **Flowline** (WH to sep), **Sales** (gas-sep to GSM), **Dump** (oil/wtr-sep to tnks), **Process** (mult-well pads), **Non-Site** (line bet well to off-site facility)

Rtest?: Is this a retest, enter Yes or No.

Recommended test time is a minimum of 15 minutes after pressure has stabilized. Enter start time and end time of test.

Method: May be tested with wellhead fluids or hydro-tested. Enter either WH or hydro.