

6. Swab back load & swab test.
7. TOH with tubing, packer and RBP.
8. Run tubing, pump and rods for production.
9. Put back on production producing both the Spergen and St. Louis.