

## Critter Creek 15-6104BW Plugging Procedure

---

- 1 MIRU
- 2 Fill the hole with fresh water
- 3 RIH with tubing to 6830' MD
- 4 RU cementers
- 5 Pump 100' cement plug from 6730-6830' MD
- 6 POOH to 1600' MD
- 7 Pump 100' cement plug from 1500 -1600' MD
- 8 POOH to 100' MD
- 9 Pump 100' cement plug from 100' MD - surfac
- 10 RD cementers and workover rig
- 11 Cut off wellhead and riser to 4' below ground
- 12 Weld on dry hole marker
- 13 Clean location and move out