

Scope of Work

The Adobe 14-14 Rentry will test the Morrow, Cherokee, and Marmaton, and Codell, and commingle if hydrocarbons are encountered

Procedure

Hold pre-job discussion with vendor crews and supervisors. Complete the Jobsite Health & Safety Meeting Report and Emergency Response Plan. Post plan in a conspicuous place on location. Make daily changes to plan throughout job. Make a copy of the plan and retain the copy in the Rig Well File.

Notes:

Day: Day Cost:

- | | |
|---|---|
| 1) Locate and test anchors on location. MIRU Service Unit. PU 4 3/4" rock bit, change over, 8x3 3/8" drill collars. | 1 |
| 2) PU and RIH with bit. Drill through surface plug, continue to 1st CIBP while picking up 2 7/8" pipe to 5400'. | 2 |
| 3) Pressure test to 500 psi for 15 minutes. Drill through CIBP. TOOH while standing back. Swab test the Marmaton. | 3 |
| 4) Continue to second CIBP at 6100'. Drill through CIBP and swab test the Morrow. | 3 |
| 5) Make Completion and Procedural Election | 4 |
| 6) | |
| 7) | |
| 8) | |
| 9) | |

\$0.00

+Rentals, Trucking, Contigent :

Total : \$0.00