

**FORM**  
**6**

Rev  
05/18

**State of Colorado**  
**Oil and Gas Conservation Commission**

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
Document Number:  402209722			
Date Received:			

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: <u>69175</u>	Contact Name: <u>Valerie Danson</u>
Name of Operator: <u>PDC ENERGY INC</u>	Phone: <u>(970) 506-9272</u>
Address: <u>1775 SHERMAN STREET - STE 3000</u>	Fax: _____
City: <u>DENVER</u> State: <u>CO</u> Zip: <u>80203</u>	Email: <u>valerie.danson@pdce.com</u>
<b>For "Intent" 24 hour notice required,</b> Name: <u>Serna, Abe</u> Tel: <u>(720) 661-7317</u>	
<b>COGCC contact:</b> Email: <u>abe.serna@state.co.us</u>	

API Number <u>05-123-21872-00</u>	Well Number: <u>21-11</u>
Well Name: <u>WEBSTER</u>	
Location: QtrQtr: <u>NENW</u> Section: <u>11</u> Township: <u>6N</u> Range: <u>65W</u> Meridian: <u>6</u>	
County: <u>WELD</u> Federal, Indian or State Lease Number: _____	
Field Name: <u>WATTENBERG</u> Field Number: <u>90750</u>	

Notice of Intent to Abandon       Subsequent Report of Abandonment

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 40.506440 Longitude: -104.631970

GPS Data:  
Date of Measurement: 04/01/2008 PDOP Reading: 1.9 GPS Instrument Operator's Name: Holly L. Tracy

Reason for Abandonment:  Dry     Production Sub-economic     Mechanical Problems  
 Other \_\_\_\_\_

Casing to be pulled:  Yes     No    Estimated Depth: 1700

Fish in Hole:  Yes     No    If yes, explain details below

Wellbore has Uncemented Casing leaks:  Yes     No    If yes, explain details below

Details: \_\_\_\_\_

**Current and Previously Abandoned Zones**

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	7160	7170			
Total: 1 zone(s)					

**Casing History**

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	451	320	451	0	VISU
1ST	7+7/8	4+1/2	10.5	7,340	500	7,340	3,128	CBL

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7110 with 2 sacks cmt on top. CIBP #2: Depth 6803 with 2 sacks cmt on top.  
 CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 100 sks cmt from 1750 ft. to 1500 ft. Plug Type: STUB PLUG Plug Tagged:   
 Set 215 sks cmt from 700 ft. to 0 ft. Plug Type: OPEN HOLE Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
(Cast Iron Cement Retainer Depth)  
 Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged:   
 Set \_\_\_\_\_ sacks at surface  
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No  
 Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. \_\_\_\_\_ inch casing Cut and Cap Date: \_\_\_\_\_  
 of \_\_\_\_\_  
 \*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_  
 Type of Cement and Additives Used: \_\_\_\_\_  
 Flowline/Pipeline has been abandoned per Rule 1105  Yes  No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

Webster 21-11 (05-123-21872) Plugging Procedure (Intent)  
 Producing Formation: Codell: 7160'-7170'  
 Upper Pierre Aquifer: 600'-1600'  
 TD: 7350' PBDT: 7326' (1/23/2004)  
 Surface Casing: 8 5/8" 24# @ 451' w/ 320 sxs  
 Production Casing: 4 1/2" 10.5# @ 7340' w/ 500 sxs cmt (TOC @ 3128' - CBL)  
 Tubing: 2 3/8" tubing set @ 7144' (12/8/2014)  
 Proposed Procedure:  
 1. MIRU pulling unit. Pull 2 3/8" tubing.  
 2. TIH with CIBP. Set BP at 7110'. Top with 2 sxs 15.8#/gal CI G cement. (Top of Codell perms @ 7160')  
 3. TIH with CIBP. Set BP at 6803'. Top with 2 sxs 15.8#/gal CI G cement. (Top of Niobrara @ 6853')  
 4. TIH with casing cutter. Cut 4 1/2" casing at 1700'. Pull cut casing.  
 5. TIH with tubing to 1750'. Mix and pump 100 sxs 15.8#/gal CI G cement down tubing. (Pierre coverage from 1700'-1500').  
 6. Pick up tubing to 700'. Mix and pump 215 sxs 15.8#/gal CI G cement down tubing. Cement should circulate to surface (Pierre coverage from 700'-surface). TOOH with tubing.  
 7. Cut surface casing 6' below ground level and weld on cap.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Valerie Danson  
 Title: Reg Tech Date: \_\_\_\_\_ Email: valerie.danson@pdce.com

