

FORM  
6

Rev  
05/18

# State of Colorado

## Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

402312324

Date Received:

### WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 47120 Contact Name: Jennifer Thomas  
Name of Operator: KERR MCGEE OIL & GAS ONSHORE LP Phone: (720) 929-6808  
Address: P O BOX 173779 Fax: \_\_\_\_\_  
City: DENVER State: CO Zip: 80217- Email: jennifer\_thomas@oxy.com

**For "Intent" 24 hour notice required,** Name: Revas, Robbie Tel: (720) 661-7242  
**COGCC contact:** Email: robbie.revas@state.co.us

API Number 05-123-30568-00  
Well Name: ADAM FARM Well Number: 8-4  
Location: QtrQtr: SWNE Section: 4 Township: 2N Range: 68W Meridian: 6  
County: WELD Federal, Indian or State Lease Number: \_\_\_\_\_  
Field Name: WATTENBERG Field Number: 90750

Notice of Intent to Abandon  Subsequent Report of Abandonment

#### Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.171241 Longitude: -105.004041  
GPS Data:  
Date of Measurement: 11/09/2009 PDOP Reading: 2.7 GPS Instrument Operator's Name: Renee Doiron  
Reason for Abandonment:  Dry  Production Sub-economic  Mechanical Problems  
 Other \_\_\_\_\_  
Casing to be pulled:  Yes  No Estimated Depth: \_\_\_\_\_  
Fish in Hole:  Yes  No If yes, explain details below  
Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below  
Details: \_\_\_\_\_

#### Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	7482	7500			
J SAND	7926	7958			
NIOBRARA	7220	7362			

Total: 3 zone(s)

#### Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	970	285	970	0	VISU
1ST	7+7/8	4+1/2	11.6	8,082	210	8,082	6,650	CBL
			Stage Tool	5,092	500	5,140	1,325	CBL

### Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7850 with 2 sacks cmt on top. CIBP #2: Depth 7150 with 2 sacks cmt on top.  
 CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:

Perforate and squeeze at 1300 ft. with 110 sacks. Leave at least 100 ft. in casing 1080 CICR Depth  
 Perforate and squeeze at 1020 ft. with 390 sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 (Cast Iron Cement Retainer Depth)

Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged:

Set \_\_\_\_\_ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Cut and Cap Date: \_\_\_\_\_

\*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_

Type of Cement and Additives Used: \_\_\_\_\_

Flowline/Pipeline has been abandoned per Rule 1105  Yes  No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Jennifer Thomas

Title: Regulatory Analyst Date: \_\_\_\_\_ Email: rscdjpostdrill@anadarko.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: \_\_\_\_\_ Expiration Date: \_\_\_\_\_

COA Type	Description

## Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
402312341	PROPOSED PLUGGING PROCEDURE
402312343	WELLBORE DIAGRAM

Total Attach: 2 Files

## General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
		Stamp Upon Approval

Total: 0 comment(s)