

## **Operations Summary Greer 34-3**

### **6/17/2021**

2:00-2:30-ROAD RIG FROM THE FIRGUSEN 35-1 TO THE GREER 34-3

2:30-3:30-SPOT IN T-SEAL AND RIG, UNWRAP LINES LEVEL UP RIG UP STRETCH LINES GET ALL ROD EQUIP READY TO LAY DOWN RODS

3:30-4:00-PULL PUMP OFF SEAT AT 10K HAD TO BEAT ON PUMP

4:00-6:00-LAY DOWN POLISH ROD 138 3/4" RODS AND A PUMP, SWIFN CLEAN UP TOOLS AND LOCATION

6:00-7:00-CREW TRAVEL

### **6/18/2021**

6:00-7:00-CREW TRAVEL AND SAFETY MTG

7:00-8:30-CHECK PSI ON WELL, O ON TBG AND CSG, CHANGE OVER FROM TBG TO RODS, N/U BOP RIG UP WORK FLOOR AND TONGS,

8:30-9:30-POOH WITH 111 JTS 2-3/8" TBG SN, 4' TBG SUB, SWIFN CLEAN UP TOOLS AND LOCATION

9:30-4:00-CREW TRAVEL BACK TO ROOSEVELT

### **6/21/2021**

6:00-7:00-CREW TRAVEL AND SAFETY MTG

7:00-7:30-CHECK PSI ON WELL O ON CSG, OPEN UP WELL RIG UP WTG WIRE-LINE

7:30-1:00-RIH WITH GAUGE RING FOR 4.5" CSG, TAG PBTB AT 3595', TOO H RIH AND SET CIBP AT 3425', TOO H RUN CBL ON 4-1/2" AND 7" CSG TO SURFACE, RIG DOWN WIRE-LINE SWIFN CLEAN UP TOOLS AND LOCATION

1:00-2:00-CREW TRAVEL

### **6/22/2021**

6:00-7:00-CREW TRAVEL AND SAFETY MTG

7:00-9:30-CHECK SPI ON WELL O ON TBG AND CSG, OPEN UP WELL RIH WITH 110 JTS 2-3/8" TBG TAG CIBP AT 3425, PRESSURE TEST CSG TO 1000 PSI WATCH FOR 15 MINUTES GOOD TEST, MIX AND PUMP 25 SXS ON TOP OF CIBP

9:30-10:30-LAY DOWN 27 JTS , 82 JTS IN EOT AT 2543', MIX AND PUMP 10 SXS CEMENT, LAY DOWN 29 JTS 5 SLOW, STAND BACK 26 STANDS

10:30-11:30-RIG UP WIRE-LINE RIH AND SHOOT PERFS AT 1720', TOO H AND TRY TO GET INJECTION RATE PRESSURE UP TO 500 PSI HELD SOLID

11:30-12:30-RIH WITH 57 JTS EOT AT 1776', MIX AND PUMP 15 SX BALANCE PLUG

12:30-1:00-LAY DOWN 9 JTS 48 JTS IN EOT AT 1500', MIX AND PUMP 20 SX BALANCE PLUG

1:00-1:30- LAY DOWN 23 JTS 25 JTS IN 86 JTS OUT EOT AT 789' MIX AND PUMP 36 SX BALANCE  
PLUG

1:30-2:00-LAY DOWN 12 JTS, 13 JTS IN EOT AT 420', MIX AND PUMP 30SXS BALANCE PLUG TO  
COVER SHOE,

2:00-3:00-LAY DOWN 13 JTS, RIG DOWN WORK FLOOR AND TONGS, N/D BOP,

3:00-3:30-PICK UP 2 JTS LAND TBG ON HANGER PUMP 13 SXS TO SURFACE LAY DOWN 2 JTS

3:30-4:30-RIG DOWN WRAP LINES GET EVERYTHING READY TO ROAD RIG TO ROOSEVELT UT

4:30-5:30-CREW TRAVEL