



00596197

 DATE **8-23-93** PAGE NO. **1**
**JOB LOG FORM 2013 R-3**

 CUSTOMER **chevron** WELL NO. **Holley 3** LEASE **cobb stringer** JOB TYPE **P/A** TICKET NO. **467763**

CHART NO.	TIME	RATE (BPM)	VOLUME (BBL) (GAL)	PUMPS		PRESSURE (PSI)		DESCRIPTION OF OPERATION AND MATERIALS
				T	C	TUBING	CASING	
	07:00							ON LOC
	07:50							RTH
	09:00							Tag on plug @ 4777'
	09:07							Start pump 1/2 BBL wash down
	09:19							Tag 4788' In rate to 1/4
	09:29							thru plug P.I. stop pump
								5550 start pump 1 BBL per min
								clean hole
	09:45							Tag bottom 5640' work
								pipe c.i.c. hole
	10:11							mix cement
	10:18							Start cement down hole
	10:44							cmnt AT NOZZEL lay IN
								plug 5640' to 5397'
								pull up to 5100' start
								Brine lay 7/8 BBL of Brine
								5200 to 3543'
	11:47							Start cement down hole
	12:10							cmnt AT NOZZEL lay IN plug
								3543' to 3291'
								pull up to 3000' lay in cement
								112 BBL
								pull up to 500'
	12:50							Start cement down hole
	13:58							cmnt AT NOZZEL lay IN plug
	14:18							cmnt at surface start
								Flush, 9 BBL acids
	14:38							Run old tree first COP
								1 stringer
								R.S. down For Day