



00202458

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

RECEIVED

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

6. IF INDIAN, ALLOTTEE OR TRIBAL NAME
COLO. OIL & GAS CONS. COMM.

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

#1 C Jones

9. WELL NO.

#1

10. FIELD AND POOL, OR WILDCAT

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 11 T6N R87W

SUNDRY NOTICES AND REPORTS ON WELLS
(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL GAS WELL OTHER

2. NAME OF OPERATOR
Altex Oil Corp.

3. ADDRESS OF OPERATOR
640 Guaranty Bank Bldg. Denver, Colo. 80202

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface 1138' SNL 676' WEL Sec 11 T6N R87W
Routt Co., Colo. *NE NE*

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

12. COUNTY OR PARISH
Routt Co.

13. STATE
Colo.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF
FRACTURE TREAT
SHOOT OR ACIDIZE
REPAIR WELL
(Other)

PULL OR ALTER CASING
MULTIPLE COMPLETE
ABANDON*
CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF
FRACTURE TREATMENT
SHOOTING OR ACIDIZING
(Other)

REPAIRING WELL
ALTERING CASING
ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Estimated date to start work. 9/22/80

1. Move in casing pulling unit.
2. Pull rods & tubing.
3. Attempt to pull all of 4 1/2" casing 3731'.
4. If we cannot recover all the 4 1/2" casing, will cut & recover what we can.
5. Run tubing & spot 10 sack cement plug at bottom of 4 1/2" casing.
6. If cut set 10 sack plug in & out of stub.
7. Set 20 sack plug at 2117' in & out of bottom of intermediate 7" casing.
8. Cut & recover 7" casing.
9. Run tubing & spot 20 sack plug in & out of 7" stub.
10. Spot 20 sack plug in & out of bottom of surface casing 9 5/8" at 76'.
11. Set 10 sack plug at surface & cut off below plow depth & weld cap on surface pipe.
12. Heavy mud will be circulated between plugs.
13. Clean & reseed location & cover pits.

FJP	<input checked="" type="checkbox"/>
HHM	<input checked="" type="checkbox"/>
JAM	<input checked="" type="checkbox"/>
JJD	<input type="checkbox"/>
RLS	<input type="checkbox"/>
SGM	<input type="checkbox"/>

18. I hereby certify that the foregoing is true and correct

SIGNED

W. P. Ruppel Jr.

TITLE

President (of Ruppel Inc.)

DATE

9/13/80

(This space for Federal or State office use)

APPROVED BY

W. P. Ruppel Jr.

TITLE

DIRECTOR
O & G CONS. COMM.

DATE

SEP 22 1980

CONDITIONS OF APPROVAL, IF ANY:

file