


# HYDROLOGY MAP

## PURVIS SE-10 MULTI-WELL PAD

SECTION: 10  
TOWNSHIP: 4N  
RANGE: 67W



NOTE: ALL DISTANCES ARE MEASURED FROM THE PURVIS 10DD WELL HEAD.

### PURVIS SE-10 MULTI-WELL PAD (WEST TO EAST)

PURVIS 10TD  
PURVIS 10DD  
PURVIS 10WD  
PURVIS 10XD

