

Trade Tool For Crossing Against Wall Backward?
Trade Tool For Crossing Against Wall Backward?
Unbalanced Weight Inside Bucket Causing Bucket To Swing Into Working Area
Unbalanced Weight Inside Bucket Causing Bucket To Swing Into Working Area
Standard, MTO, ID 0.0, ID 0.0, ID 0.0, Units

Calibration Report

Calibration File: Jobsgenie SLB HD.db
Calibrated Performed: Wed Jun 23 08:14:57 2010 by SIU (JavaScript 1.5)
Calibrated Tool(s): Wireline

Inverting Key Calibration Report

Serial Number	Wireline
Tool Model	Wireline
Tool Length	0.000 in, 14.57 ft, 14.57 ft, 0.000
Calibrator Value	1.0 Ω/Ω%
Background Reading	0.0 Ω/Ω
Calibrator Reading	0.0 Ω/Ω
Sensitivity	0.0000 Ω/Ω%/psi

Cement Bond Log Calibration Report

Serial Number	7500-CCL
Tool Model	7500-CCL
Calibrated Performed	Wed Jun 23 07:39:54 2010

Phase Correction	47.5	ft
Depth Correction	0.0	ft

Signal Zero	0.0		mV
Calibration Amplitude	61.1000	61.1000	mV
Calibration Travel Time	1.4000	1.4000/1000	s
Gain	1.4571	2.0	V

Date	23 Jun 2010	12 Jun 2010	
Time	7:39:54	12:47:00	