

**FORM**  
**6**  
Rev  
12/05

**State of Colorado**  
**Oil and Gas Conservation Commission**

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
----	----	----	----

Document Number:

400373298

Date Received:

01/23/2013

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 100322 Contact Name: Leah Perkins  
 Name of Operator: NOBLE ENERGY INC Phone: (970) 286-5925  
 Address: 1625 BROADWAY STE 2200 Fax: (970) 304-5099  
 City: DENVER State: CO Zip: 80202 Email: LPerkins@nobleenergyinc.com

**For "Intent" 24 hour notice required,** Name: HICKEY, MIKE Tel: (970) 302-1024  
**COGCC contact:** Email: mike.hickey@state.co.us

API Number 05-013-06302-00 Well Number: MC 9-3  
 Well Name: VON REYN  
 Location: QtrQtr: NENW Section: 9 Township: 1N Range: 69W Meridian: 6  
 County: BOULDER Federal, Indian or State Lease Number: \_\_\_\_\_  
 Field Name: WATTENBERG Field Number: 90750

Notice of Intent to Abandon  Subsequent Report of Abandonment

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 40.071040 Longitude: -105.124090  
 GPS Data:  
 Date of Measurement: 04/18/2007 PDOP Reading: 1.8 GPS Instrument Operator's Name: Paul Tappy  
 Reason for Abandonment:  Dry  Production for Sub-economic  Mechanical Problems  
 Other \_\_\_\_\_  
 Casing to be pulled:  Yes  No Estimated Depth: 5000  
 Fish in Hole:  Yes  No If yes, explain details below  
 Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below  
 Details: WHEN WELL WAS BEING PREPPED FOR COLORADO SCHOOL OF MINES EXPERIMENT WIRELINE TOOLS AND RBP WERE LEFT IN HOLE @6850', FOLLOWING UNSUCCESSFUL FISHING ATTEMP.

**Current and Previously Abandoned Zones**

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	7752	7762	09/19/2007	B PLUG CEMENT TOP	6850
NIOBRARA	7369	7638	09/19/2007	B PLUG CEMENT TOP	6850

Total: 2 zone(s)

**Casing History**

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	23.0	666	465	666	0	VISU
1ST	7+7/8	4+1/2	11.6	7,909	250	7,909	6,820	CBL

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6850 with 2 sacks cmt on top. CIBP #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 100 sks cmt from 5000 ft. to 4800 ft. Plug Type: STUB PLUG Plug Tagged:   
Set 50 sks cmt from 2500 ft. to 2400 ft. Plug Type: OPEN HOLE Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
(Cast Iron Cement Retainer Depth)

Set 300 sacks half in. half out surface casing from 775 ft. to 0 ft. Plug Tagged:

Set \_\_\_\_\_ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_

\*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_

Type of Cement and Additives Used: \_\_\_\_\_

Flowline/Pipeline has been abandoned per Rule 1103  Yes  No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Julie Ottoson

Title: Base Production Tech Date: 1/23/2013 Email: JOttoson@nobleenergyinc.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: BURN, DIANA Date: 3/29/2013

#### **CONDITIONS OF APPROVAL, IF ANY:**

Expiration Date: 9/28/2013

- 1) Provide 24 hour notice of MIRU to Mike Hickey at 970-302-1024 or e-mail at Mike.Hickey@state.co.us.
- 2) For 775' plug: pump plug and displace, if not circulated to surface, shut-in, WOC 4 hours and tag plug – must be 610' or shallower. Leave at least 100' cement in the casing for each plug.
- 3) Properly abandon flowlines as per Rule 1103.

Production records back to 9/07 need to be corrected to TA and no production.

### Attachment Check List

Att Doc Num	Name
400373298	FORM 6 INTENT SUBMITTED
400373515	WELLBORE DIAGRAM
400373517	PROPOSED PLUGGING PROCEDURE
400373519	WELLBORE DIAGRAM

Total Attach: 4 Files

### General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
Engineer	need wireline tix for RBP/cement top - req'd; production records need to be corrected - shown continuous production since 2007	2/22/2013 11:17:57 AM
Permit	Well completion report dated 9/29/1993.	1/24/2013 9:03:04 AM

Total: 2 comment(s)