

FORM
6Rev
12/05State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

400529021

Date Received:

12/18/2013

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 100322

Contact Name: Seth Gordon

Name of Operator: NOBLE ENERGY INC

Phone: (720) 587-2288

Address: 1625 BROADWAY STE 2200

Fax: (970) 304-5099

City: DENVER State: CO Zip: 80202

Email: sgordon@nobleenergyinc.com

For "Intent" 24 hour notice required,

Name: MONTOYA, JOHN

Tel: (970) 3974124

COGCC contact:

Email: john.montoya@state.co.us

API Number 05-123-24798-00

Well Name: WASTE MANAGEMENT USX Y

Well Number: 3-13

Location: QtrQtr: SWSW Section: 3 Township: 2N Range: 64W Meridian: 6

County: WELD

Federal, Indian or State Lease Number:

Field Name: WATTENBERG

Field Number: 90750

☒ Notice of Intent to Abandon☐ Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.162330

Longitude: -104.544430

GPS Data:

Date of Measurement: 06/06/2007

PDOP Reading: 1.6

GPS Instrument Operator's Name: Paul Tappy

Reason for Abandonment: ☐ Dry ☒ Production for Sub-economic ☐ Mechanical Problems☐ OtherCasing to be pulled: ☒ Yes☐ No

Estimated Depth: 2500

Fish in Hole: ☐ Yes☒ No

If yes, explain details below

Wellbore has Uncemented Casing leaks: ☐ Yes☒ No

If yes, explain details below

Details:

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
J SAND	7492	7512			

Total: 1 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	905	441	905	10	VISU
1ST	7+7/8	4+1/2	11.6	7,630	230	7,630	6,300	CBL
			Stage Tool	5,578	600	5,578	3,910	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7442 with 2 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 25 sks cmt from 5628 ft. to 5528 ft. Plug Type: CASING Plug Tagged: ☐
Set 100 sks cmt from 2600 ft. to 2400 ft. Plug Type: STUB PLUG Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 400 sacks half in. half out surface casing from 1005 ft. to 0 ft. Plug Tagged: ☒

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No *ATTACH JOB SUMMARY

Technical Detail/Comments:

WASTE MANAGEMENT USX Y #3-13

PROCEDURE:

- 1) MIRU Workover rig, pump & tank.
- 2) POOH w/ 2 3/8" tbg and lay down.
- 3) RU WL. RIH w/CIBP. Set CIBP @ 7442', dump bail 2 sx of cement on top.
- 4) Unland casing. Cut casing off +/- 2500'. POOH with casing laying down on trailer.
- 5) RIH w/ workstring to pump (100) sx stub plug where csg was pulled. If maintain circulation, do not need to tag plug.
- 6) POOH w/workstring to 1005'. Pump approx 400 sx shoe plug. Cement to surface.
- 7) RIH. Tag shoe plug. Add cement if needed.
- 8) Cut surface casing off 6'-8' below ground.
- 9) Clean up location. Reclaim location. RDMO.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Stephanie Dionne
Title: Base Production Tech Date: 12/18/2013 Email: sdionne@nobleenergyinc.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: SCHLAGENHAUF, MARK Date: 12/24/2013

CONDITIONS OF APPROVAL, IF ANY: _____ Expiration Date: 6/23/2014

<u>COA Type</u>	<u>Description</u>
	<p>Note changes to plugging procedure:</p> <ol style="list-style-type: none"> 1) Submit Form 42 electronically to COGCC 48 hours prior to MIRU. 2) If unable to pull casing, contact COGCC for plugging modifications. 3) Leave at least 100' cement in the wellbore for each plug. 4) Add 100' casing plug to cover DV tool at 5578'. 5) For 1005' plug: pump plug and displace, shut-in, WOC 4 hours and tag plug – must be 700' or shallower. If shoe plug not circulated to surface then place 5-10 sx inside casing at surface. 6) Properly abandon flowlines as per Rule 1103. Once properly abandoned file electronic form 42.

Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
400529021	FORM 6 INTENT SUBMITTED
400529078	WELLBORE DIAGRAM
400529080	PROPOSED PLUGGING PROCEDURE
400529081	WELLBORE DIAGRAM

Total Attach: 4 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>

Total: 0 comment(s)