

Replug By Other Operator

Document Number:

400639464

Date Received:

07/03/2014

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.
A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 96155 Contact Name: James Kopp
 Name of Operator: WHITING OIL AND GAS CORPORATION Phone: (303) 357-1410
 Address: 1700 BROADWAY STE 2300 Fax: (303) 390-4292
 City: DENVER State: CO Zip: 80290 Email: james.kopp@whiting.com

For "Intent" 24 hour notice required, Name: Rains, Bill Tel: (970) 590-6480
COGCC contact: Email: bill.rains@state.co.us

API Number 05-123-20474-00 Well Number: 3
 Well Name: WALKER
 Location: QtrQtr: NWNW Section: 31 Township: 10N Range: 58W Meridian: 6
 County: WELD Federal, Indian or State Lease Number: _____
 Field Name: TERRACE SOUTH Field Number: 81550

Notice of Intent to Abandon Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.799964 Longitude: -103.914918
 GPS Data:
 Date of Measurement: _____ PDOP Reading: _____ GPS Instrument Operator's Name: _____
 Reason for Abandonment: Dry Production for Sub-economic Mechanical Problems
 Other Re-enter to re-plug
 Casing to be pulled: Yes No Estimated Depth: _____
 Fish in Hole: Yes No If yes, explain details below
 Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below
 Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth

Total: 0 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	277	195	277	0	

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth _____ with _____ sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
 CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
 CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 60 sks cmt from 5700 ft. to 5500 ft. Plug Type: OPEN HOLE Plug Tagged:
 Set 60 sks cmt from 1700 ft. to 1500 ft. Plug Type: OPEN HOLE Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
(Cast Iron Cement Retainer Depth)

Set 110 sacks half in. half out surface casing from 350 ft. to 0 ft. Plug Tagged:
 Set _____ sacks at surface
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No
 Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____
 *Wireline Contractor: _____ *Cementing Contractor: _____
 Type of Cement and Additives Used: _____
 Flowline/Pipeline has been abandoned per Rule 1103 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:

Re-Plug and Abandon Procedure

1. Notify COGCC at least 48-hours prior to the start of operations using a Form 42. Verify with James Kopp that this is completed prior to moving the rig in.
2. The following is a procedure to drill out existing cement plugs and re-plug in order to properly isolate the Walker 3 well. Take GPS coordinates of well location. Send information to: James.Kopp@whiting. James Kopp com (303) 357-14103.
3. MIRU Workover Rig. Mob-in pump, swivel, tank, and 2-7/8" PH-6 workstring. NU 7-1/16" 5K BOP w/ 2-7/8" pipe rams on top and blind rams on bottom, pressure test high and low. PU full gauge 7-7/8" bit & TIH on 2-7/8" tubing.
4. Drill out existing cement plugs down to approximately 1,410 ftKB.
5. Clean out to approximately 5,800 ftKB.
6. Once depth has been reached, TOOH with 2-7/8" workstring standing back.
7. MIRU gyro equipment. PU tools and RIH while logging down to 5,800 ftKB. POOH while logging, LD tools.
8. MIRU cement crew. Pressure test surface lines to 2,000psi. Mix and pump 60 sks, API Class G, 1.15 cu-ft/sk, 15.8 ppg cement, balancing plug at 5,700 ftKB. TOOH with 2-7/8" workstring standing back. Let cement cure overnight.
9. TIH with 2-7/8" workstring. Tag TOC with EOT, record depth.
10. MIRU cement crew. Pressure test surface lines to 2,000psi. Mix and pump 60 sks, API Class G, 1.15 cu-ft/sk, 15.8 ppg cement, balancing plug at 1,700 ftKB. TOOH with 2-7/8" workstring standing back. Let cement cure overnight.
11. TIH with 2-7/8" workstring. Tag TOC with EOT, record depth.
12. MIRU cement crew. Pressure test surface lines to 2,000psi. Mix and pump 110 sks, API Class G, 1.15 cu-ft/sk, 15.8 ppg cement, balancing plug from 350 ftKB to surface. TOOH with 2-7/8" workstring, LD on float.
13. Cut off WH to 5' below GL and fill hole.
14. Weld on cap with plugging information plate. Backfill cellar.
15. Reclaim disturbed surface.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Kristi McRedmond
 Title: Regulatory Technician Date: 7/3/2014 Email: regulatory@petro-fs.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: SUTPHIN, DIRK

Date: 7/18/2014

CONDITIONS OF APPROVAL, IF ANY: _____

Expiration Date: 1/17/2015

COA Type	Description
	Note changes to submitted form. 1) Provide 24 hour notice of MIRU via electronic Form 42. 2) If 5700'-5500' plug cannot be set as proposed, set 60 sx cement plug above the Niobrara top, in the Pierre, below 3800' or between 3300'-1700'. 3) Submit Form 6 – Subsequent Report of Abandonment within 30 days of plugging in accordance with Rule 311.
	1) As built GPS coordinates will be provided on the form 6, SRA. 2) Operator will submit a Form 42 - Offset Mitigation Completed for the re-plugged well, referencing the API Number of the proposed horizontal well. 3) Operator will submit a Form 4 to report date Final Reclamation will commence. Final reclamation should begin as soon as practicable.

Attachment Check List

Att Doc Num	Name
400639464	FORM 6 INTENT SUBMITTED
400639550	SURFACE OWNER CONSENT
400639551	WELLBORE DIAGRAM
400639554	WELLBORE DIAGRAM
400639555	LOCATION PHOTO
400639556	OTHER

Total Attach: 6 Files

General Comments

User Group	Comment	Comment Date
Engineer	Casing history: Surface casing depth is 277' cemented with 195 sx.	7/18/2014 3:19:31 PM
Permit	Rec. inspection report in file from 3/2008.	7/7/2014 6:45:17 AM

Total: 2 comment(s)