

Document Number:
401140838

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 69175 Contact Name: Kelsi Welch
 Name of Operator: PDC ENERGY INC Phone: (303) 831-3974
 Address: 1775 SHERMAN STREET - STE 3000 Fax: _____
 City: DENVER State: CO Zip: 80203 Email: kelsi.welch@pdce.com

For "Intent" 24 hour notice required, Name: Gomez, Jason Tel: (970) 573-1277
 COGCC contact: Email: jason.gomez@state.co.us

API Number 05-123-20004-00 Well Number: 23-11
 Well Name: J&L FARMS
 Location: QtrQtr: NWNW Section: 23 Township: 6N Range: 64W Meridian: 6
 County: WELD Federal, Indian or State Lease Number: _____
 Field Name: WATTENBERG Field Number: 90750

Notice of Intent to Abandon Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.477170 Longitude: -104.524970
 GPS Data:
 Date of Measurement: 12/07/2008 PDOP Reading: 1.5 GPS Instrument Operator's Name: Holly L. Tracy
 Reason for Abandonment: Dry Production Sub-economic Mechanical Problems
 Other _____
 Casing to be pulled: Yes No Estimated Depth: _____
 Fish in Hole: Yes No If yes, explain details below
 Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below
 Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	6884	6895			
NIOBRARA	6710	6726			

Total: 2 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	389	275	389	0	
1ST	7+7/8	4+1/2	10.5	7,059	379	7,059	0	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6834 with 2 sacks cmt on top. CIBP #2: Depth 6660 with 2 sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 60 sks cmt from 590 ft. to 0 ft. Plug Type: CASING Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged:

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1103 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:

J&L Farms 23-11 (05-123-20004)/Plugging Procedure (Intent)
Producing Formation: Codell 6884'-6895' Niobrara 6710'-6736'
TD: 7122' PBDT: 7014'
Surface Casing: 8 5/8" 24# @ 389' w/ 275 sxs
Production Casing: 4 1/2" 10.5# @ 7059' w/379 sks cmt with annular fill (TOC at Surface - CBL)

Tubing: 2 3/8" tubing set at 6871'. (3/6/2009)

Proposed Procedure:

1. MIRU RU pulling unit. Pull 2 3/8" tubing.
2. RU wireline company.
3. TIH with CIBP. Set CIBP at 6834'. Top with 2 sxs 15.8#/gal CI G cement.
4. TIH with CIBP. Set CIBP at 6660'. Top with 2 sxs 15.8#/gal CI G cement.
5. Run CBL from 3500' to surface to confirm annular fill in 2007. (If new CBL shows poor cement, cut and pull casing at 590'.)
6. TIH with tubing to 590'. Mix and pump 60 sxs of 15.8#/gal CI G cement down tubing. Cement should circulate to surface. (If new CBL shows poor cement, TIH with tubing to 640'. Mix and pump 185 sxs of 15.8#/gal CI G cement down tubing. Cement should circulate to surface.)
7. Cut surface casing 6' below ground level and weld on cap.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Kelsi Welch

Title: Regulatory Tech Date: _____ Email: kelsi.welch@pdce.com

