

Document Number:
401265823

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 69175 Contact Name: Kelsi Welch
 Name of Operator: PDC ENERGY INC Phone: (303) 831-3974
 Address: 1775 SHERMAN STREET - STE 3000 Fax: _____
 City: DENVER State: CO Zip: 80203 Email: kelsi.welch@pdce.com

For "Intent" 24 hour notice required, Name: Gomez, Jason Tel: (970) 573-1277
 COGCC contact: Email: jason.gomez@state.co.us

API Number 05-123-24575-00 Well Number: 5
 Well Name: RILEY
 Location: QtrQtr: NWNW Section: 13 Township: 5N Range: 65W Meridian: 6
 County: WELD Federal, Indian or State Lease Number: _____
 Field Name: WATTENBERG Field Number: 90750

Notice of Intent to Abandon Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.405360 Longitude: -104.619140
 GPS Data:
 Date of Measurement: 04/07/2009 PDOP Reading: 2.4 GPS Instrument Operator's Name: ROBERT D. THOMAS
 Reason for Abandonment: Dry Production Sub-economic Mechanical Problems
 Other _____
 Casing to be pulled: Yes No Estimated Depth: _____
 Fish in Hole: Yes No If yes, explain details below
 Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below
 Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
NIOBRARA	6754	6940			
CODELL	7024	7036	11/19/2008	B PLUG CEMENT TOP	6994

Total: 2 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	479	340	479	0	
1ST	7+7/8	4+1/2	11.6	7,287	580	7,287	170	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6704 with 2 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 60 sks cmt from 675 ft. to 0 ft. Plug Type: CASING Plug Tagged:
Set 40 sks cmt from 170 ft. to 0 ft. Plug Type: ANNULUS Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
(Cast Iron Cement Retainer Depth)

Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged:

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1103 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:

Riley 5 (05-123-24575)/Plugging Procedure (Intent)
Producing Formation: Niobrara 6754'-6940'
Plugged Back Formations: Codell 7024'-7036'
Existing CIBP Set At: 6994' with 1 sx cement
TD: 7300' PBTD: 7268'
Surface Casing: 8 5/8" 24# @ 479' w/340 sxs.
Production Casing: 4 1/2" 11.6# @ 7287' w/ 580 sks cmt. (TOC at 170' - CBL.)

Tubing: 2 3/8" tubing set at 6722'. (12/18/2008)

Proposed Procedure:

1. MIRU RU pulling unit. Pull tubing.
2. RU wireline company. Run Gyro survey from 6900' to surface.
3. TIH with CIBP. Set BP at 6704'. Top with 2 sxs 15.8#/gal CI G cement.
4. TIH with tubing to 675'. Mix and pump 60 sxs 15.8#/gal CI G cement down tubing. Cement should circulate to surface.
5. Fill production casing annulus from top of annular cement at 170' to surface using 1 1/4" tubing. (Estimated volume 40 sxs.)
6. Cut surface casing 6' below ground level and weld on cap.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Kelsi Welch

Title: Production Tech Date: _____ Email: kelsi.welch@pdce.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____

Date: _____

CONDITIONS OF APPROVAL, IF ANY: _____

Expiration Date: _____

COA Type

Description

COA Type	Description

Attachment Check List

Att Doc Num

Name

Att Doc Num	Name
401265841	WELLBORE DIAGRAM
401265843	WELLBORE DIAGRAM

Total Attach: 2 Files

General Comments

User Group

Comment

Comment Date

User Group	Comment	Comment Date
		Stamp Upon Approval

Total: 0 comment(s)