

FORM
6Rev
05/18

State of Colorado

Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

402118036

Date Received:

08/30/2019

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 10112

Contact Name: Mike Jumper

Name of Operator: FOUNDATION ENERGY MANAGEMENT LLC

Phone: (918) 526-5545

Address: 5057 KELLER SPRINGS RD STE 650

Fax: (918) 585-1660

City: ADDISON State: TX Zip: 75001

Email: mjumper@foundationenergy.com

For "Intent" 24 hour notice required,

Name: Welsh, Brian

Tel: (719) 325-6919

COGCC contact:

Email: brian.welsh@state.co.us

API Number 05-125-09287-00

Well Name: HILLTOP

Well Number: 13-5

Location: QtrQtr: NWSW Section: 5 Township: 1S Range: 45W Meridian: 6

County: YUMA

Federal, Indian or State Lease Number:

Field Name: REPUBLICAN

Field Number: 73275

☒ Notice of Intent to Abandon☐ Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 39.994900

Longitude: -102.446440

GPS Data:

Date of Measurement: 05/16/2008

PDOP Reading: 2.7

GPS Instrument Operator's Name: SCOTT DEMANCHE

Reason for Abandonment:

☐ Dry☒ Production Sub-economic☐ Mechanical Problems☐ OtherCasing to be pulled: ☐ Yes☒ No

Estimated Depth:

Fish in Hole: ☐ Yes☒ No

If yes, explain details below

Wellbore has Uncemented Casing leaks:

☐ Yes☒ No

If yes, explain details below

Details:

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
NIOBRARA	2300	2320			

Total: 1 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	9+7/8	7		426	180	426	0	CALC
1ST	6+1/4	4+1/2		2,484	151	2,500	0	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 2250 with 2 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 40 sks cmt from 476 ft. to 0 ft. Plug Type: CASING Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged: ☐

Set 10 sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. _____ inch casing Cut and Cap Date: _____
of _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1105 ☐ Yes ☐ No *ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Mike Jumper

Title: D&C Intern Date: 8/30/2019 Email: mjumper@foundationenergy.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: SUTPHIN, DIRK Date: 9/30/2019

CONDITIONS OF APPROVAL, IF ANY: _____

Expiration Date: 3/29/2020

COA Type	Description
	<p>Plugging:</p> <ol style="list-style-type: none"> 1) Provide 48 hour notice of MIRU via electronic Form 42 - Start of Plugging Operations. 2) After placing the shallowest hydrocarbon isolating plug, operator must wait a sufficient time to confirm static conditions. If at any time after placing this plug there is evidence of pressure or of fluid migration, contact COGCC engineering before continuing operations. 3) Shoe plug: Tag plug 50' above surface casing shoe, if cement does not circulate to surface. 4) Surface plug: Cement from 50' to surface in casing and annulus. 5) With the Form 6 SRA operator must provide written documentation which positively affirms each COA from the approved Notice of Intent to Abandon has been addressed. <p>Bradenhead:</p> <p>Prior to starting plugging operations a bradenhead test shall be performed if there has not been a reported bradenhead test within the 60 days immediately preceding the start of plugging operations. The Form 17 shall be submitted within 10 days of the test.</p> <ol style="list-style-type: none"> 1) If before opening the Bradenhead valve, the beginning pressure is greater than 25 psi, sampling is required. 2) If pressure remains at the conclusion of the test, or if any liquids were present during the test, sampling is required. <p>Sampling shall comply with Operator Guidance - Bradenhead Testing and Reporting Instructions. If samples are collected, copies of all final laboratory analytical results shall be provided to the COGCC within three (3) months of collecting the samples. If there is a need for sampling, contact COGCC engineering for verification of plugging procedure.</p> <p>Venting during plugging:</p> <p>Operator shall implement measures to control venting, to protect health and safety, and to ensure that vapors and odors from well plugging operations do not constitute a nuisance or hazard to public welfare.</p> <p>Flowlines:</p> <p>Properly abandon flowlines per Rule 1105. File electronic Form 42 once abandonment is complete. Within 30 days of an operator completing abandonment requirements for an off-location flowline or crude oil transfer line, the operator must submit a Flowline Report, Form 44.</p>

Attachment Check List

Att Doc Num	Name
402118036	FORM 6 INTENT SUBMITTED
402134843	WELLBORE DIAGRAM
402162771	WELLBORE DIAGRAM
402162772	WELLBORE DIAGRAM

Total Attach: 4 Files

General Comments

User Group	Comment	Comment Date
Engineer	Casing: Per Form 5 - Surface casing depth is 426' and cement quantity 180 sks. Production casing depth is 2484' and cement quantity 151 sks. CBL appears to confirm TOC = surface. Plugging: Revised to show plug depth from 50' below surface casing shoe to surface, and top off annulus.	09/30/2019
Engineer	rt'd to DRAFT - operator request WBD clarifications	08/19/2019

Total: 2 comment(s)