

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

Document Number:  
403337072

Date Received:

OGCC Operator Number: 22111 Contact Name: Cal St. J9ohn

Name of Operator: D & B VENTURES Phone: (720) 545-5624

Address: \_\_\_\_\_ Fax: \_\_\_\_\_

City: DENVER State: CO Zip: \_\_\_\_\_ Email: cal.stjohn@state.co.us

**For "Intent" 24 hour notice required,** Name: Labowskie, Steve Tel: (970) 946-5073

**COGCC contact:** Email: steve.labowskie@state.co.us

Type of Well Abandonment Report:  Notice of Intent to Abandon  Subsequent Report of Abandonment

API Number 05-067-05236-00

Well Name: FERGUSON (OWP) Well Number: 1

Location: QtrQtr: SWNW Section: 34 Township: 33N Range: 12W Meridian: N

County: LA PLATA Federal, Indian or State Lease Number: \_\_\_\_\_

Field Name: RED MESA Field Number: 72890

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 37.062728 Longitude: -108.144956

GPS Data: GPS Quality Value: \_\_\_\_\_ Type of GPS Quality Value: \_\_\_\_\_ Date of Measurement: \_\_\_\_\_

Reason for Abandonment:  Dry  Production Sub-economic  Mechanical Problems

Other Orphaned Well

Casing to be pulled:  Yes  No Estimated Depth: \_\_\_\_\_

Fish in Hole:  Yes  No If yes, explain details below

Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below

Details: Well was reported leaking gas to surface after plugging on 11/10/1962. Wellbore to be re-entered and additional cement plugs placed in wellbore. Well was drilled using cable tools and casing was shot off at 1957' and pulled before plugging according to 11/16/1962 Plugging Record Doc #00677394 and 2/7/1963 Completion Report Doc #0677395.

**Current and Previously Abandoned Zones**

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
SANASTEE	2705	2796	11/03/1962	B PLUG CEMENT TOP	2705
Total: 1 zone(s)					

**Casing History**

Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status
SURF	12+0/1	10+3/4	H-40	32	0	57	25	57	0	VISU
1ST	7+0/1	5+0/1	J-55	11.5	0	2705	75	2705	2045	CALC

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set	100	sks cmt from	1500	ft. to	1400	ft.	Plug Type: OPEN HOLE	Plug Tagged: <input checked="" type="checkbox"/>
Set	100	sks cmt from	1246	ft. to	1146	ft.	Plug Type: OPEN HOLE	Plug Tagged: <input checked="" type="checkbox"/>
Set	100	sks cmt from	926	ft. to	826	ft.	Plug Type: OPEN HOLE	Plug Tagged: <input checked="" type="checkbox"/>
Set	100	sks cmt from	700	ft. to	600	ft.	Plug Type: OPEN HOLE	Plug Tagged: <input checked="" type="checkbox"/>
Set	100	sks cmt from	400	ft. to	300	ft.	Plug Type: OPEN HOLE	Plug Tagged: <input checked="" type="checkbox"/>

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
(Cast Iron Cement Retainer Depth)

Set 100 sacks half in. half out surface casing from 100 ft. to 0 ft. Plug Tagged:   
 Set \_\_\_\_\_ sacks at surface  
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No  
 Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Number of Days from Setting Surface Plug to Capping or Sealing the Well: \_\_\_\_\_  
 Surface Plug Setting Date: \_\_\_\_\_ Cut and Cap Date: \_\_\_\_\_  
 \*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_  
 Type of Cement and Additives Used: \_\_\_\_\_  
 Flowline/Pipeline has been abandoned per Rule 1105  Yes  No

**Technical Detail/Comments:**

Well was previously plugged 11/16/1962 and casing was shot off at 1957'. During plugging surface casing was cemented from 60' to surface. See attached WBD for additional 1962 plugging information. Wellbore re-entry will require wellbore to be washed down and drilled to 1500'.

Plug #1 - Pump 100 sx @ 1500'. Tag required.  
 Plug #2 - Pump 100 sx @ 1246'. Tag required.  
 Plug #3 - Pump 100 sx @ 926'. Tag required.  
 Plug #4 - Pump 100 sx @ 700'. Tag required.  
 Plug #5 - Pump 100 sx @ 400'. Tag required. Check well for bubbling before pumping surface plug don't pump if bubbles are present.  
 Plug #6 - Pump 100 sx @ 100' w/cement returns to surface adding accelerant to slurry.  
 After 5 days.  
 Fill cement to surface in all annuli w/additional sx as needed.  
 Cut, cap, and bury per COGCC rules/regulations/guidelines.

This is resubmittal of previously approved but expiring on 3/21/2023 Form 6I document number 403149479. Contractor equipment availability and adverse winter weather conditions have delayed the Orphaned Well Program Southwest Plugging Project requiring Form 6I resubmittal. The plugging project is underway with P&A work scheduled but will not be completed prior to Form 6I expiration

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Cal St. John  
 Title: OWP West Field Specialist Date: \_\_\_\_\_ Email: cal.stjohn@state.co.us

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_

Date: \_\_\_\_\_

**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_

Expiration Date: \_\_\_\_\_

**COA Type**                      **Description**

COA Type	Description
0 COA	

### Attachment List

**Att Doc Num**              **Name**

Att Doc Num	Name
403337073	WELLBORE DIAGRAM

Total Attach: 1 Files

### General Comments

**User Group**              **Comment**

**Comment Date**

User Group	Comment	Comment Date
		Stamp Upon Approval

Total: 0 comment(s)