

BLM BRADENHEAD TEST REPORT FORM

Lease #: I22IND _____ Well Name Mosketti 43-33 # 3 API# Req'd #03-045-_____
 MOO-C _____ #05-067-09195
 14-20- _____ Operator Simcoe, LLC Date: 9-9-24 #05-083-_____
 75 _____
 COC _____
 FEE/CA#: _____
 QQ: NESE Sec 33 Twp 34 (N) Range 8 (W) Minerals: Federal-Indian-State-Fee

Well Status: On-Line (Flowing/Pumping/Plunger lift/Clock/Intermittent; Shut-in (GSI/TA), P&A Type: Gas SWD Injection POW
 Number of Casings if known: (circle) Two Two with liner Three Three with liner

STEP 1: CLOSE all BLM & approved-to-vent surface & intermediate VALVES 10-14 days prior to test. (BLM well BHD valves shall normally be closed unless specific BLM authorization has been approved to vent casing to atmosphere as a remediation procedure.)
BRADENHEAD TEST RECORDING

STEP 2: CERTIFY that all buried valves are in **OPEN** position:
 If Buried Bradenhead vlv, Confirmed Open? Y/N
 If Buried Intermediate vlv, Confirmed Open? Y/N
Expose piping for all BLM witnessed tests to demonstrate that buried valve is "open".

Elapsed time	Tubing Fm	Tubing Fm	Prod. Casing	Intermed. Casing	Surface Casing
Initial Pressure	# 49	#	# 50	#	# 11 Pressure
____:____ Min:Sec	# 49	#	# 50	#	Flow Char. D
05:00	50		50		Flow Char. NF
10:00	50		50		Flow Char. NF
15:00					Flow Char.
20:00					Flow Char.
25:00					Flow Char.
30:00					Flow Char.
				Instantaneous Ending Pressure	<u>0</u> TSTM

STEP 3: USING calibrated mechanical (2# accuracy) or digital Gauge, **MEASURE** Initial Tubing & Casing Pressures & **Record** on chart. Too small to measure = "TSTM".

STEP 4: If initial Surface casing Is >25# (>5# within sensitive areas), **SAMPLE** gas using 10 individual cylinder purges & record cylinder # _____.

STEP 5: Open & flow Bhd vlv. monitoring flow Character. Record other casing pressures within 1st 5 min, then @ 5, 10, 15, 20, 25, 30min. Record Surface Csg. flow characteristic. "Required time to monitor" on reverse. **IF < 5 min. to blow down** show in "elapsed time" column of Chart; **Record below the time to "whisper" & time to "no flow"** if different.

BHD to "w" in ____ min ____ sec & to "NF" in ____ min ____ sec.

INT to "w" in ____ min ____ sec & to "NF" in ____ min ____ sec

STEP 6: Leave Bradenhead open & repeat above procedure with Intermediate casing. Record in Intermediate Test Record Chart

Record flow characteristic by letters: NF=no flow; D=gas diminished to no flow; G=continuous gas, W=whisper, V=vapor; S=surge; VAC=vacuum H=water; M=mud.

Water/mud character:(circle) clear, fresh, salty, sulfur, black (Gas sample analysis to be submitted with BHD test to BLM)

STEP 7: CLOSE ALL VALVES unless approved to vent.

REMARKS:

Note size of valve: BHD: 1" needle valve or (1/2)" 3/4", 1", 2"
 INTERMEDIATE: 1" needle valve or 1/2" 3/4", 1", 2"

Clarifying remarks: Puff to zero

INTERMEDIATE TEST RECORDING

Elapsed Time	Tubing Fm	Tubing Fm	Prod. Casing	Intermed. Casing
Initial Pressure	#	#	#	# Pressure
____:____ Min:Sec	#	#	#	Flow Char.
05:00				Flow Char.
10:00		N	A	Flow Char.
15:00				Flow Char.
20:00				Flow Char.
25:00				Flow Char.
30:00				Flow Char.
				Ending Pressure

Tested by: Heather Alexander (signature) Heather Alexander

Phone: 505-947-0367 DATE: 9-9-24

Witnessed by _____ BLM/COGCC