

FORM
6Rev
12/05State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80205 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Date Received:

Document Number:

400165907

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 100185

Contact Name: Marina Ayala

Name of Operator: ENCANA OIL & GAS (USA) INC

Phone: (720) 876-3663

Address: 370 17TH ST STE 1700

Fax: (720) 876-4663

City: DENVER State: CO Zip: 80202-56

Email: marina.ayala@encana.com

24 hour notice required, contact: Name: LONGWORTH, MIKE Tel: (970) 812-7644
Email: mike.longworth@state.co.us

API Number 05-103-07671-00

Well Name: GOVERNMENT

Well Number: 1-3

Location: QtrQtr: NENW Section: 3 Township: 4S Range: 102W Meridian: 6

County: RIO BLANCO

Federal, Indian or State Lease Number: 44572

Field Name: DOUGLAS CREEK SOUTH

Field Number: 17901

☒ Notice of Intent to Abandon☐ Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 39.733300

Longitude: -108.834811

GPS Data:

Data of Measurement: 02/06/2007

PDOP Reading: 2.9

GPS Instrument Operator's Name: BRIAN BAKER

Reason for Abandonment: ☐ Dry ☒ Production for Sub-economic ☐ Mechanical Problems☐ OtherCasing to be pulled: ☐ Yes☒ No

Top of Casing Cement:

Fish in Hole: ☐ Yes☒ No

If yes, explain details below

Wellbore has Uncemented Casing leaks: ☐ Yes☐ No

If yes, explain details below

Details:

Current and Previously Abandoned Zones

| Formation | Code | Perf. Top | Perf. Bottom | Date | Method of Isolation | Plug Depth |
|-----------|--------|-----------|--------------|------|---------------------|------------|
| MANCOS B | MNCS B | 2714 | 3037 | | | |

Total: 1 zone(s)

Casing History

| Casing Type | Size of Hole | Size of Casing | Weight Per Foot | Setting Depth | Sacks Cement | Cement Bot | Cement Top | Status |
|-------------|--------------|----------------|-----------------|---------------|--------------|------------|------------|--------|
| SURF | 12+1/4 | 8+5/8 | 24 | 213 | 175 | 213 | 0 | CALC |
| 1ST | 7+7/8 | 5+1/2 | 17 | 2,352 | 150 | 2,352 | 0 | CBL |
| 2ND | 7+7/8 | 5+1/2 | 15.5 | 3,154 | 150 | 3,154 | 2,352 | CBL |

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 2660 with 12 sacks cmt on top. CIPB #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIPB #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set _____ sks cmt from _____ ft. to _____ ft. in Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. in Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. in Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. in Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. in Plug Type: _____ Plug Tagged: ☐

Perforate and squeeze at 263 ft. with 77 sacks. Leave at least 100 ft. in casing 273 CIGR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CIGR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CIGR Depth

(Cast Iron Cement Retainer Depth)

Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged: ☐

Set 175 sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No *ATTACH JOB SUMMARY

Provide Technical Detail:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Marina Ayala

Title: Permitting Technician Date: _____ Email: marina.ayala@encana.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY: _____

Expiration Date: _____

Attachment Check List

| Att Doc Num | Name |
|-------------|-----------------------------|
| 400166289 | PROPOSED PLUGGING PROCEDURE |
| 400166290 | WELLBORE DIAGRAM |
| 400166291 | WELLBORE DIAGRAM |

Total Attach: 3 Files

General Comments

| User Group | Comment | Comment Date |
|------------|---------|--------------|
| | | |

Total: 0 comment(s)