



Date Received:

05/19/2011

Document Number:

400166682

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: <u>10084</u>	Contact Name: <u>Judy Glinisty</u>
Name of Operator: <u>PIONEER NATURAL RESOURCES USA INC</u>	Phone: <u>(303) 675-2858</u>
Address: <u>1401 17TH ST STE 1200</u>	Fax: <u>(303) 294-1275</u>
City: <u>DENVER</u> State: <u>CO</u> Zip: <u>80202</u>	Email: <u>Judy.Glinisty@pxd.com</u>
For "Intent" 24 hour notice required, COGCC contact:	
Name: <u>DURAN, JOHN</u>	Tel: <u>(719) 846-4715</u>
Email: <u>john.duran@state.co.us</u>	

API Number <u>05-071-09246-00</u>	Well Number: <u>22-30</u>
Well Name: <u>BAYWATCH</u>	
Location: QtrQtr: <u>SENW</u> Section: <u>30</u> Township: <u>34S</u> Range: <u>64W</u> Meridian: <u>6</u>	
County: <u>LAS ANIMAS</u>	Federal, Indian or State Lease Number: _____
Field Name: <u>PURGATOIRE RIVER</u>	Field Number: <u>70830</u>

☒ Notice of Intent to Abandon ☐ Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: <u>37.057780</u>	Longitude: <u>-104.607620</u>
GPS Data:	
Data of Measurement: <u>07/09/2007</u>	PDOP Reading: <u>2.2</u> GPS Instrument Operator's Name: <u>JAMES ROYBAL</u>
Reason for Abandonment: <input type="checkbox"/> Dry <input checked="" type="checkbox"/> Production for Sub-economic <input type="checkbox"/> Mechanical Problems	
<input type="checkbox"/> Other _____	
Casing to be pulled: <input type="checkbox"/> Yes <input checked="" type="checkbox"/> No	Top of Casing Cement: _____
Fish in Hole: <input type="checkbox"/> Yes <input checked="" type="checkbox"/> No	If yes, explain details below
Wellbore has Uncemented Casing leaks: <input type="checkbox"/> Yes <input checked="" type="checkbox"/> No	If yes, explain details below
Details: _____	

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
VERMEJO COAL	691	957			

Total: 1 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
CONDUCTOR	14+3/4	12+3/4	0	10	0	0	0	CALC
SURF	11	8+5/8	23	284	103	284	0	CBL
1ST	7+7/8	5+1/2	17	1,168	251	1,168	0	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 650 with 2 sacks cmt on top. CIPB #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIPB #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set _____	sks cmt from _____	ft. to _____	ft. in _____	Plug Type: _____	Plug Tagged: <input type="checkbox"/>
Set _____	sks cmt from _____	ft. to _____	ft. in _____	Plug Type: _____	Plug Tagged: <input type="checkbox"/>
Set _____	sks cmt from _____	ft. to _____	ft. in _____	Plug Type: _____	Plug Tagged: <input type="checkbox"/>
Set _____	sks cmt from _____	ft. to _____	ft. in _____	Plug Type: _____	Plug Tagged: <input type="checkbox"/>
Set _____	sks cmt from _____	ft. to _____	ft. in _____	Plug Type: _____	Plug Tagged: <input type="checkbox"/>

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 12 sacks half in. half out surface casing from 340 ft. to 240 ft. Plug Tagged: ☐

Set 12 sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☒ Yes ☐ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No *ATTACH JOB SUMMARY

Technical Detail/Comments:

Vermejo 691' - 694'
Vermejo 815' - 818'
Vermejo 955' - 957'

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Grayson Pranin

Title: Operations Engineer Date: 5/19/2011 Email: Grayson.Pranin@pxd.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: SUTPHIN, DIRK Date: 6/6/2011

CONDITIONS OF APPROVAL, IF ANY: _____ Expiration Date: 12/5/2011

1) Provide 48 hour notice of MIRU to John Duran at 719-846-4715 or email John.Duran@state.co.us.

Attachment Check List

Att Doc Num	Name
400166682	FORM 6 SUBMITTED

Total Attach: 1 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>

Total: 0 comment(s)