



DE	ET	OE	ES
----	----	----	----

Date Received:  
04/26/2011

Document Number:  
1634688

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.  
 A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 10082 Contact Name: CRAIG HANAGAN  
 Name of Operator: MANZANO LLC Phone: (575) 623-1996  
 Address: P O BOX 2107 Fax: (575) 625-2620  
 City: ROSWELL State: NM Zip: 88202 Email: CHANAGAN@QUESTOFFICE.NET

**For "Intent" 24 hour notice required,** Name: CRAIG HANAGAN Tel: (575) 910-6154  
**COGCC contact:** Email: CHANAGAN@QUESTOFFICE.NET

API Number 05-055-06306-00 Well Number: 1  
 Well Name: MAGNINO 2 FEE  
 Location: QtrQtr: NWNE Section: 2 Township: 30S Range: 69W Meridian: 6  
 County: HUERFANO Federal, Indian or State Lease Number: \_\_\_\_\_  
 Field Name: WILDCAT Field Number: 99999

Notice of Intent to Abandon  Subsequent Report of Abandonment

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: \_\_\_\_\_ Longitude: \_\_\_\_\_  
 GPS Data:  
 Date of Measurement: \_\_\_\_\_ PDOP Reading: \_\_\_\_\_ GPS Instrument Operator's Name: \_\_\_\_\_  
 Reason for Abandonment:  Dry  Production for Sub-economic  Mechanical Problems  
 Other \_\_\_\_\_  
 Casing to be pulled:  Yes  No Top of Casing Cement: \_\_\_\_\_  
 Fish in Hole:  Yes  No If yes, explain details below  
 Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below  
 Details: \_\_\_\_\_

**Current and Previously Abandoned Zones**

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth

Total: 0 zone(s)

**Casing History**

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
CONDUCTOR	20	13+3/8	48	95	175	95	0	
SURF	12+1/2	9+5/8	36	1,198	360	1,198	0	

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIPB #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIPB #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 75 sks cmt from 3038 ft. to 2888 ft. Plug Type: OPEN HOLE Plug Tagged:   
Set 75 sks cmt from 1240 ft. to 1030 ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
(Cast Iron Cement Retainer Depth)  
Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged:   
Set 15 sacks at surface  
Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No  
Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: 11/01/2010  
\*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: HALIBURTON  
Type of Cement and Additives Used: PREMIUM CLASS "G"  
Flowline/Pipeline has been abandoned per Rule 1103  Yes  No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: CRAIG HANAGAN  
Title: OPERATIONS FOREMAN Date: 3/16/2011 Email: CHANAGAN@QUESTOFFICE.NET

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: SUTPHIN, DIRK Date: 10/26/2011

#### CONDITIONS OF APPROVAL, IF ANY:

### Attachment Check List

Att Doc Num	Name
1634688	FORM 6 SUBSEQUENT SUBMITTED

Total Attach: 1 Files

**General Comments**

<b>User Group</b>	<b>Comment</b>	<b>Comment Date</b>
Engineer	Cement tickets for plugs attached to Form 5. Plug at 3038'-2888' is above all shows on mudlog.	6/24/2011 4:30:55 PM

Total: 1 comment(s)