

FORM
6Rev
12/05

State of Colorado

Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

400317167

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 100322

Contact Name: Leah Perkins

Name of Operator: NOBLE ENERGY INC

Phone: (970) 286-5925

Address: 1625 BROADWAY STE 2200

Fax: (970) 304-5099

City: DENVER State: CO Zip: 80202

Email: LPerkins@nobleenergyinc.com

For "Intent" 24 hour notice required,

Name: EDELEN, RANDY

Tel: (970) 520-2531

COGCC contact:

Email: randy.edelen@state.co.us

API Number 05-123-15914-00

Well Name: SPIKE ST GWS

Well Number: D 16-12

Location: QtrQtr: NWSW Section: 16 Township: 3N Range: 64W Meridian: 6

County: WELD

Federal, Indian or State Lease Number: 70/7884-S

Field Name: WATTENBERG

Field Number: 90750

☒ Notice of Intent to Abandon☐ Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.224020

Longitude: -104.563800

GPS Data:

Date of Measurement: 09/22/2006

PDOP Reading: 2.5

GPS Instrument Operator's Name: Paul Tappy

Reason for Abandonment: ☐ Dry ☒ Production for Sub-economic ☐ Mechanical Problems☐ OtherCasing to be pulled: ☒ Yes☐ No

Estimated Depth: 3750

Fish in Hole: ☐ Yes☒ No

If yes, explain details below

Wellbore has Uncemented Casing leaks: ☐ Yes☒ No

If yes, explain details below

Details: WELL IS LOCATED 150' FROM NEW HORIZONTAL WELL (GUTTERSEN ST D16-65-1HN). SUSSEX HAS ALREADY BEEN SQUEEZED, LEAVING ONLY A CODELL COMPLETION. NIOBRARA RESERVES CAPTURED BY NEW HORIZONTAL WELL.

Current and Previously Abandoned Zones

Formation	Code	Perf. Top	Perf. Bottom	Date	Method of Isolation	Plug Depth
CODELL	CODL	6982	6992			
SUSSEX	SUSX	4354	4398	07/19/2004	SQUEEZED	

Total: 2 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	389	265	389	0	VISU
1ST	7+7/8	3+1/2	9.3	7,122	450	7,122	3,862	CBL
S.C. 1.1	7+7/8	3+1/2	9.3	7,122	100	4,500	3,862	CBL
S.C. 1.2	7+7/8	3+1/2	9.3	7,122	150	4,398	4,354	CALC
S.C. 1.3	7+7/8	3+1/2	9.3	7,122	100	4,398	4,354	CALC

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6882 with 2 sacks cmt on top. CIPB #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIPB #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 100 sks cmt from 3850 ft. to 3650 ft. Plug Type: STUB PLUG Plug Tagged: ☒
Set 40 sks cmt from 2500 ft. to 2420 ft. Plug Type: OPEN HOLE Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 275 sacks half in. half out surface casing from 489 ft. to 0 ft. Plug Tagged: ☒
Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____
*Wireline Contractor: _____ *Cementing Contractor: _____
Type of Cement and Additives Used: _____
Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No *ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Julie Ottoson
Title: Base Prod Operations Tech Date: _____ Email: JOttoson@nobleenergyinc.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY:

Expiration Date: _____

Attachment Check List

Att Doc Num	Name
400317231	WELLBORE DIAGRAM
400317232	PROPOSED PLUGGING PROCEDURE
400317233	WELLBORE DIAGRAM

Total Attach: 3 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>

Total: 0 comment(s)